

**Cover Page**



**JS-MD 3**

**AIRCRAFT FLIGHT MANUAL**



## JS-MD 3 AIRCRAFT FLIGHT MANUAL

Type:	JS-MD Single
Model:	JS-MD 3
Serial number:	3, MD011
Registration Number:	D-KSTM
Document number:	MD10-AFM-00-001
Title:	JS-MD 3 Aircraft Flight Manual

Issue	00
Date of issue	13.09.17
Responsible for content	

Issue 00 of this JS-MD 3 Aircraft Flight Manual is approved under the authority of DOA EASA.21J.603

Sections 2, 3, 4 and 5.2 are approved by the EASA through XXX.

Copyright ©:

M&D Flugzeugbau GmbH & Co.KG  
Streeker Straße 5b  
D-26446 Friedeburg

-All rights reserved-



## JS-MD 3 Aircraft Flight Manual

MD10-AFM-00-001

Issue: 00.21

Date: 13.09.2017

*Intentionally left blank*

## 0 Document Management

### 0.1 Record of revision

Issue	Date	Reason for Change
00	13.09.2017	Initial Issue

## 0.2 List of effective sections

Section	Revision	Date	Number of Pages	Reference
0	00	13.09.2017	6	Initial Issue
1	00	13.09.2017	6	Initial Issue
2	00	13.09.2017	20	Initial Issue
3	00	13.09.2017	14	Initial Issue
4	00	13.09.2017	32	Initial Issue
5	00	13.09.2017	9	Initial Issue
6	00	13.09.2017	14	Initial Issue
7	00	13.09.2017	30	Initial Issue
8	00	13.09.2017	10	Initial Issue
9	00	13.09.2017	2	Initial Issue
10	00	13.09.2017	2	Initial Issue
11	00	13.09.2017	1	Initial Issue

### 0.3 Record of amendments

Date of Issue/ Revision	Date of Insertion	Signature



## 0.4 Table of contents

<b>JS-MD 3 AIRCRAFT FLIGHT MANUAL .....</b>	<b>i</b>
<b>0 Document Management .....</b>	<b>0-1</b>
0.1 Record of revision .....	0-1
0.2 List of effective sections .....	0-2
0.3 Record of amendments .....	0-3
0.4 Table of contents .....	0-4
<b>1 General .....</b>	<b>1-1</b>
1.1 Introduction .....	1-1
1.2 Certification basis .....	1-2
1.3 Warnings, cautions and notes .....	1-2
1.4 Descriptive data .....	1-3
1.5 Technical data .....	1-4
1.6 Three-view drawing .....	1-5
<b>2 Limitations .....</b>	<b>2-1</b>
2.1 Introduction .....	2-1
2.2 Airspeed limits .....	2-2
2.3 Airspeed indicator marking .....	2-4
2.4 Power plant fuel and oil .....	2-5
2.5 Power plant instrument markings .....	2-5
2.6 Mass .....	2-5
2.7 Centre of gravity .....	2-7
2.8 Approved manoeuvres .....	2-9
2.9 Flight load factor limits .....	2-10
2.10 Flight crew .....	2-11
2.11 Types of operation .....	2-12
2.12 Minimum equipment list .....	2-13
2.13 Aerotow and winch launching .....	2-14
2.14 Other limitations .....	2-15
2.15 Limitations placards .....	2-18
<b>3 Emergency procedures .....</b>	<b>3-1</b>
3.1 Introduction .....	3-1
3.2 Canopy jettison .....	3-1

3.3	Bailing out.....	3-2
3.4	Stall recovery.....	3-3
3.5	Spin recovery .....	3-4
3.6	Spiral dive recovery.....	3-5
3.7	Excessive sideslip recovery .....	3-6
3.8	Engine failure – Jet turbine.....	3-7
3.9	Engine Fire .....	3-7
3.10	Electrical fire.....	3-8
3.11	Other emergencies.....	3-9
<b>4</b>	<b>Normal operating procedures.....</b>	<b>4-1</b>
4.1	Introduction.....	4-1
4.2	Rigging and de-rigging .....	4-1
4.3	Daily inspection .....	4-7
4.4	Pre-flight check.....	4-13
4.5	Normal procedures and recommended speeds.....	4-14
<b>5</b>	<b>Performance .....</b>	<b>5-1</b>
5.1	Introduction.....	5-1
5.2	Approved data .....	5-3
5.3	Non-approved information.....	5-7
<b>6</b>	<b>Weight and balance .....</b>	<b>6-1</b>
6.1	Introduction.....	6-1
6.2	Weight and balance record .....	6-1
6.3	Permitted payload-range and CG envelope.....	6-3
6.4	Optimisation of centre of gravity.....	6-10
<b>7</b>	<b>System description .....</b>	<b>7-1</b>
7.1	Introduction.....	7-1
7.2	Cockpit controls.....	7-2
7.3	Landing gear system .....	7-15
7.4	Seats and safety harness.....	7-16
7.5	Pitot and static system .....	7-17
7.6	Airbrake system.....	7-19
7.7	Baggage compartment.....	7-20
7.8	Water ballast system .....	7-21
7.9	Power plant .....	7-23
7.10	Fuel system .....	7-23





7.11	Electrical system .....	7-23
7.12	Miscellaneous equipment.....	7-27
<b>8</b>	<b>Handling and maintenance .....</b>	<b>8-1</b>
8.1	Aircraft inspection periods.....	8-2
8.2	Ground handling.....	8-3
8.3	Cleaning and care .....	8-5
8.4	Long-term storage.....	8-9
<b>9</b>	<b>Supplements.....</b>	<b>9-1</b>
9.1	Introduction.....	9-1
9.2	List of ancillary equipment.....	9-1
<b>10</b>	<b>Service Bulletins .....</b>	<b>10-1</b>
<b>11</b>	<b>STCs and Minor Change Approvals.....</b>	<b>11-1</b>



# 1 General

## 1.1 Introduction

This Flight Manual has been prepared to provide pilots and instructors with all the information required for safe and efficient operation of the JS-MD 3. All the data that is required by the Airworthiness Requirement CS-22 to furnish the pilot is contained in this manual. It also contains supplementary data supplied by the sailplane manufacturer.

The JS-MD 3 is a high-performance sailplane and not a trainer. Even though it possesses excellent performance and handling qualities, it can only be flown by a skilled pilot who complies with the limitations and recommendations set out in this manual.

If a Jet Sustainer System is fitted, use this manual in combination with the latest approved MD10-AFM-00-002 JS-MD 3 Jet Sustainer Flight Manual Supplement.



## 1.2 Certification basis

This aircraft, with production designation (type) JS-MD single (model JS-MD 3) has been approved by the European Aviation Safety Agency (EASA) in accordance with CS-22 including Amendment AMC 22.1555 (a), AMC 22.1585 (f).

The category of airworthiness is U (Utility).

## 1.3 Warnings, cautions and notes

The following definitions apply to warnings, cautions and notes used in this Flight Manual.

**WARNING:** means that the non-observation of the corresponding procedure leads to an immediate or important degradation of the flight safety.

**CAUTION:** means that the non-observation of the corresponding procedure leads to a minor or to a longer term degradation of the flight safety.

**NOTE:** draws the attention on any special item not directly related to safety but which is important or unusual.

## 1.4 Descriptive data

The JS-MD 3 is a high-performance single-seat sailplane of conventional layout with a T-tail. Two wingspan configurations (15 m and 18 m) can be selected, both of which feature full-span flaperons.

The cockpit is designed to protect the pilot in the event of a crash. Safety features include a crumple zone in the forward structure. The wing structure consists of spar caps made of carbon fibre rovings and skins of carbon fibre fabric. The wings are connected with a tongue and fork arrangement, secured with one main pin. The airbrakes are a triple blade design on the upper surface of the wing.

Boundary layer control is achieved on the main wing bottom surfaces, the horizontal stabilizer and vertical fin. All control surface hinge gaps are sealed with Mylar strips and Teflon-coated tape.

The water ballast system consists of two main tanks, each integral to a wing and holding approximately 78 litres of water, and two trim tanks in the vertical fin. The tail ballast tanks consist of an expendable tank of approximately 5.8 litres and a non-expendable tank of approximately 8.9 litres. The 18 m wing tips also feature integral tanks, with a capacity of approximately 17 litres each. The landing gear consists of a 5 inch retractable sprung main landing gear with a pneumatic retractable tail wheel.

All controls are automatically connected during rigging.

Optionally a retractable jet engine approved for sustained flight can be fitted.


## 1.5 Technical data

<b>Geometry</b>	<b>JS-MD 3 15 m</b>	<b>JS-MD 3 18 m</b>
Wing Span	15 m / 49.21 ft	18 m / 59.06 ft
Wing Area	8.75 m <sup>2</sup> / 94.18 ft <sup>2</sup>	9.95 m <sup>2</sup> / 107.10 ft <sup>2</sup>
Aspect Ratio	25.4	32.8
Fuselage Length	6.86 m / 22.51 ft	
Fuselage Height	1.22 m / 4.00 ft	
<b>Weight</b>	<b>JS-MD 3 15 m</b>	<b>JS-MD 3 18 m</b>
Maximum Weight	525 kg / 1157 lbs	600 kg / 1323 lbs
Empty Weight (without engine)	270 kg / 579 lbs	282 kg / 618 lbs
Empty Weight (with engine)	286 kg / 617 lbs	298kg / 657 lbs
Maximum Weight without water ballast	415 kg / 915 lbs	430 kg / 948 lbs
Wing Loading (min) (70kg pilot)	40.0 kg/m <sup>2</sup> / 8.2 lb/ft <sup>2</sup>	37.0 kg/m <sup>2</sup> / 7.58 lb/ft <sup>2</sup>
Wing Loading (max)	60.0 kg/m <sup>2</sup> / 12.3 lb/ft <sup>2</sup>	60.3 kg/m <sup>2</sup> / 12.35 lb/ft <sup>2</sup>
<b>Glide performance</b>	<b>JS-MD 3 15 m</b>	<b>JS-MD 3 18 m</b>
Best Glide Ratio	50	55
Best Glide Speed at MAUW	125 km/h	120 km/h
Flap Setting 4 (9° - 13.5°)	67 kts	65 kts
Best Glide Speed at 450 kg	110 km/h	105 km/h
Flap Setting 4 (9 ° - 13.5°)	59 kts	57 kts
Sink Rate (200km/h / MAUW)	1.57 m/s 309 ft/min	1.60 m/s 315 ft/min

**Table 1.5-1**

## 1.6 Three-view drawing

### 1.6.1 JS-MD 3 15 m



**Figure 1.6-1 JS-MD 3 15 m**

1.6.2 JS-MD 3 18 m




Figure 1.6-2 JS-MD 3 18 m



## **2 Limitations**

### **2.1 Introduction**

Section 2 includes operating limitations, instrument markings, and basic placards necessary for safe operation of the aircraft, its engine (if fitted), standard systems and standard equipment.

The limitations included in this section and in Section 9 have been approved by the EASA.



## 2.2 Airspeed limits

Speed limitations and their operational significance are shown in Table 2.2-1 below:

Speed		IAS	Remarks
$V_{NE}$	Never exceed speed	280 km/h 151 kts	Do not exceed this speed in any operation and do not use more than 1/3 of control deflection
$V_{RA}$	Rough air speed	207 km/h 112 kts	Do not exceed this speed except in smooth air, and then only with caution. Examples of rough air are lee-wave rotor, thunderclouds etc.
$V_A$	Manoeuvring speed	207 km/h 112 kts	Do not make full or abrupt control movement above this speed, because under certain conditions the sailplane may be overstressed by full control movement.
$V_{FE}$	Maximum flap extended speed	See Table 2.2-2	Do not exceed these speeds with the given flap setting.
$V_W$	Maximum winch launching speed	150 km/h 81 kts	Do not exceed this speed during winch or auto tow launching
$V_T$	Maximum aerotow speed	180 km/h 97 kts	Do not exceed this speed during aerotow.
$V_{LO}$	Maximum landing gear operating speed	180 km/h 97 kts	Do not extend or retract the landing gear above this speed.
$V_{PO_{max}}$	Maximum power plant extension & retraction speed	Refer to JS-MD 3 Jet Sustainer Flight Manual Supplement Section 2.2.	
$V_{PE}$	Power plant extended maximum permitted speed		

**Table 2.2-1**

Table 2.2-2 below lists the maximum allowable airspeed for each flap setting:


Flap setting	Deflection (°)	V <sub>FE</sub>	
		15	18 m
1	-3°	280 km/h 151 kts	
2	+0°		
3	+5°	230 km/h / 124 kts	
4	+13.5°	165 km/h / 89 kts	
5	+16.6°	165 km/h / 89 kts	
L	+20°	160 km/h / 86 kts	

**Table 2.2-2**

The maximum allowable airspeeds for each flap setting are indicated on the airspeed indicator (ASI) with white triangles next to the flap position number, as indicated in Figure 2.2-1 (ASI in km/h) and Figure 2.2-2 (ASI in knots).









**Figure 2.2-1 ASI in km/h**



**Figure 2.2-2 ASI in knots**

## Airspeed indicator marking

The airspeed indicator markings and their colour code significance are given in Table 2.2-3:

Marking		IAS		Significance
		15m	18m	
White Arc		97 to 160 km/h 52 to 86kts		Positive Flap Operating Range. (Lower limit is $1.1 V_{SO}^1$ in landing configuration at maximum weight. Upper limit is maximum speed permissible with flaps extended positive)
Green Arc		103 to 207 km/h 56 to 112 kts		Normal Operating Range. (Lower limit is $1.1V_{S1}^2$ at maximum weight and most forward c. g. with flaps neutral. Upper limit is rough air speed.)
Yellow Arc		207 to 280 km/h 112 to 151 kts		Manoeuvres must be conducted with caution and only in smooth air.
Red Line		280 km/h 151 kts		Maximum speed limit for all operations.
Blue line		Refer to Jet Sustainer Supplement Section 2.3		Best rate-of-climb speed $V_Y$ (if engine is fitted)
Yellow Triangle		101 km/h 55 kts		Approach speed at maximum weight without water ballast.

**Table 2.2-3**

<sup>1</sup>  $V_{SO}$  is defined as the stall speed at maximum weight, in the landing configuration, with the CG in the most unfavourable position, See CS 22.49.

<sup>2</sup>  $V_{S1}$  is defined as the stall speed at maximum weight, in a specific selected configuration, with the CG in the most unfavourable position, See CS 22.49.

## 2.3 Power plant fuel and oil

Refer to MD10-AFM-00-002 JS-MD 3 Jet Sustainer Flight Manual Supplement Section 2.4.

## 2.4 Power plant instrument markings

Refer to MD10-AFM-00-002 JS-MD 3 Jet Sustainer Flight Manual Supplement Section 2.5.

## 2.5 Mass

The mass limitations for the JS-MD 3 are given in Table 2.5-1:

Mass definition	Mass limits	
	15 m	18 m
Maximum All-Up Mass	525 kg 1157 lbs	600 kg 1323 lbs
Maximum All-Up Mass without water ballast	415 kg 913 lbs	430 kg 1045 lbs
Maximum Take-Off Mass for winch launching	525 kg 1157 lbs	600 kg 1323 lbs
Maximum Take-Off Mass for cloud flying or aerobatics	418 kg 922 lbs	
Maximum Mass of non-lifting parts at MAUW	320 kg 705 lbs	
Maximum Mass in luggage compartment	1 kg 2.2 lbs	

**Table 2.5-1**

Table 2.5-2 displays the reduction in allowable non-lifting weight for take off weights below the maximum allowed weights.

Aircraft all-up Weight	Non-lifting mass structural limit	
	15 m	18 m
350 kg 771.6 lbs	266 kg 586 lbs	216 kg 477 lbs
375 kg 826.7 lbs	288 kg 635 lbs	240 kg 529 lbs
400 kg 881.8 lbs	305 kg 672 lbs	238 kg 525 lbs
425 kg 937.0 lbs	310 kg 683 lbs	263 kg 580 lbs
450 kg 992.1 lbs	314 kg 692 lbs	310 kg 683 lbs
MAUW	320 kg 705 lbs	320 kg 705 lbs

**Table 2.5-2**

**NOTE:** Increase the take-off weight by adding water in the tips to take advantage of a higher non-lifting mass.

**WARNING:** Only soft items such as canopy covers and jackets may be stored in the baggage compartment. This is necessary to prevent injury to the pilot during an emergency landing.


## 2.6 Centre of gravity

Table 2.6-1 displays the allowable CG range for the JS-MD 3 in the 15 m and 18 m configurations:

Centre of Gravity range (in flight)	Distance from datum	
	15 m	18 m
Most forward CG location (325kg to 400 kg)	270 mm 10.63 in.	270 mm 10.63 in.
Most forward CG location (at MAUW)	305 mm 12.01 in.	315 mm 12.40 in.
Most aft CG location	390 mm 15.35 in.	398 mm 15.67 in.

**Table 2.6-1**

The datum is defined as the wing leading edge at the wing root rib, i.e. on the wing immediately outboard of the wing-fuselage fairing.



**Figure 2.6-1**

The correct aircraft attitude for weighing is defined as with the aft fuselage boom forward of the fin positioned at gradient of 1000:18, as illustrated in Figure 2.6-1.

Table 2.6-2 gives the forward and rear centre of gravity limits (no payload) for different empty masses that will allow a cockpit range of 70kg to 115kg.

Empty mass		Empty Centre of Gravity range			
		Forward limit to allow a maximum cockpit load of 115kg (253 lbs)		Rear limit to allow a minimum cockpit load of 70kg (154 lbs)	
Kg	lbs	15 m	18 m	15 m	18 m
260	573	675 mm 26.6 in	675 mm 26.6 in	669 mm 26.3 in	679 mm 26.7 in
270	596	660 mm 26.0 in	660 mm 26.0 in	660 mm 26.0 in	668 mm 26.3 in
280	618	646 mm 25.4 in	646 mm 25.4 in	649 mm 25.5 in	659 mm 25.9 in
290	640	637 mm 25.1 in	633 mm 24.9 in	640 mm 25.2 in	650 mm 25.6 in
300	662	630 mm 24.8 in	626 mm 24.6 in	632 mm 24.9 in	641 mm 25.3 in
310	684	623 mm 24.5 in	619 mm 24.4 in	624 mm 24.6 in	634 mm 24.9 in
320	706	616 mm 24.3 in	612 mm 24.1 in	616 mm 24.3 in	626 mm 24.7 in

**Table 2.6-2**

If the calculated empty centre of gravity falls outside of this envelope, the minimum and maximum cockpit loads must be determined using the formula given in the MD10-AMM-00-002 JS-MD 3 Aircraft Maintenance Manual Section 9.



## **2.7 Approved manoeuvres**

This aircraft is certified in the Utility category (U). The following aerobatic manoeuvres are permitted in the 15 m and 18 m configuration:

- Lazy Eight
- Chandelle
- Steep turns
- Positive loops
- Stall turns
- Spins

Refer to Section 4.5.11 for the recommended entry speeds for each manoeuvre.



## 2.8 Flight load factor limits

The minimum and maximum approved manoeuvring loads are given in the Table 2.8-1 below:

Condition	IAS		Load factor
	15 m	18 m	
Maximum positive manoeuvre	207 km/h 112 kts		+ 5.3
Maximum negative manoeuvre	207 km/h 112 kts		- 2.65
Maximum positive manoeuvre	280 km/h 151 kts		+ 4.0
Maximum negative manoeuvre	280 km/h 151 kts		- 1.5
Maximum positive manoeuvre with airbrakes open	280 km/h 151 kts		+ 3.5
Maximum positive manoeuvre with flaperons in landing configuration	160 km/h 86 kts		+ 4.0

Table 2.8-1



## 2.9 Flight crew

The minimum and maximum pilot mass is indicated on the cockpit placard.

Minimum cockpit load: 70 kg (154.3 lbs)

Maximum cockpit load: 115 kg (253.5 lbs)

**CAUTION:** If the measured empty CG is not within the normal empty mass CG range, the minimum and maximum cockpit loads must be calculated and the cockpit placard values corrected accordingly.

Pilots below the minimum weight must add cockpit ballast according to the centre of gravity calculations as explained in Section 6.

**NOTE:** The term “cockpit load” includes pilot, parachute, baggage and any other temporary equipment.

Contact the manufacturer or approved service station if assistance is required.



## 2.10 Types of operation

The JS-MD 3 is approved for:

- VFR day
- Cloud flying in 15 and 18 m configuration without water ballast where national regulations permit

**NOTE:** For Cloud flying the take-off mass must not exceed 418kg (922 lbs) as listed in Section 2.5, and engine must be retracted (if fitted).

Refer to Section 2.11 for the minimum equipment required for cloud flying.

## 2.11 Minimum equipment list

Instruments and other equipment on the minimum equipment list must be approved. Refer to the accessory approval section in the MD10-AMM-00-001 JS-MD 3 Aircraft Maintenance Manual for details.

### The minimum equipment:

- Pitot-static type airspeed indicator, scale 50 to 300 km/h (27 to 162 kts), colour markings in accordance with Section 0
- Altimeter.
- Aircraft compass or suitable GPS navigational system with redundant battery supply.
- 4-point symmetrical seat harness.
- Operating placards.
- Control surface gap seals (Mylar seals) on all control surfaces.

### Additional instrumentation required when flying with water ballast:

- Instrumentation indicating outside air temperature with the probe installed in the fuselage nose.

### Additional instrumentation required for cloud flying:

- Turn and bank indicator or artificial horizon.
- Variometer to indicate vertical speed.

### Additional instrumentation required if engine is fitted:

Refer to JS-MD 3 Jet Sustainer Flight Manual Supplement Section 2.9

## 2.12 Aerotow and winch launching

Maximum approved towing speeds and recommended weak link ratings for the JS-MD 3 are listed in Table 2.12-1.

Launch Method	Maximum Speed	Recommended Weak link
Winch or ground launch	150 km/h / 81 kts	600 daN (E.g. Tost weak link #3, Red)
Aerotow	180 km/h / 97 kts	600 daN (Tost weak link #4, Blue)

**Table 2.12-1**

For Aerotow launching:

Tow rope length	15 m & 18 m configurations
Approved	40 to 60 m (131 to 197 ft)
Recommended	45 to 55 m (148 to 180 ft)

**Table 2.12-2**

**NOTE:** Only textile ropes may be used for aerotow launching.

## 2.13 Other limitations

### 2.13.1 Limitations when flying with water ballast

Intentional manoeuvres not permitted when flying with water ballast:

- Loops
- Chandelles
- Lazy Eights
- All aerobatic manoeuvres listed in the Aerobatic category
- Intentional spins

Cloud flying is not permitted when flying with water ballast.

### 2.13.2 Temperature restrictions without water ballast

Flights in conditions below  $-30\text{ °C}$  are prohibited. When the outside air temperature is less than  $-30\text{ °C}$ , a descent to lower altitudes (higher temperatures) must be conducted.

**WARNING:** Icing of even small amounts of water ballast may cause structural damage to the wing tanks and fin structures.

**WARNING:** Sub-zero temperatures may result in the controls freezing up. Move controls, including airbrakes, regularly to reduce the risk of control freezing.

### 2.13.3 Temperature restrictions when carrying water

Flights with water ballast are prohibited in conditions where there is a risk of icing. When the outside air temperature is below 0 °C (32 °F), water ballast must be dumped or a descent to lower altitudes (higher temperatures) must be conducted. Flying in temperatures below freezing with water in the non-expendable tank is not allowed.

**WARNING:** Icing water ballast may cause structural damage to the wing and fin structures. Avoid flying in icing conditions, or storage of the aircraft with water tanks filled.

**WARNING:** Dumped water may freeze at the valve outlets at outside temperature well above the freezing point.

**CAUTION:** Currently no additives (e.g. anti-freeze) are approved to lower the water freezing point.

### 2.13.4 Limitations while dumping water ballast

Dumping water ballast takes approximately five minutes. While dumping, the fuselage static ports may get temporarily blocked by water entering the static ports. This may cause the airspeed indicator to give incorrect readings during the descents. These erroneous readings may continue until the main tanks are empty.

**CAUTION:** Avoid high speed flying (within 30 km/h or 16 kts of limit speeds) when water is dumped. Monitor approach speeds and approach angles as the actual approach speed may be indicated incorrectly. It is recommended to change to the alternate static port (if fitted) while dumping water.



### 2.13.5 Limitations of high speed flight

If there are any indications that an airspeed limit may be exceeded (e.g. when flying in wave rotor, near thunderstorms or other turbulent conditions), extend the airbrakes carefully before exceeding 200 km/h (108 kts). In emergencies the airbrakes may be extended up  $V_{NE}$ , as defined in Section 2.2. Above 250 km/h (135 kts) the airbrakes are sucked open abruptly after unlocking, resulting in a sharp deceleration which may result in pilot induced oscillations (P.I.O.). This effect is least in the negative flap position. When the airbrakes are extended in possible turbulent conditions the Rough Airspeed ( $V_{RA}$ ) should not be exceeded. Decelerate to 200 km/h or 108 kts before closing airbrakes. Airbrake forces above 220 km/h are very high.

**WARNING:** The deceleration associated with the opening of the brakes at high speeds may result in the pilot's head shattering the canopy if the seat harness straps are not tight. Ensure that the seat harness straps are tight before operating the airbrakes at high speeds.

### 2.13.6 Altitude limitations

The aircraft is limited to an altitude of 9000 m or 30000 ft AMSL.

See Section 4.5.8 for more details.

**NOTE:** For further placards, refer to the Maintenance Manual.



## 2.14 Limitations placards

The placard given in Figure 2.14-1 is fixed to the left side wall of the cockpit and contains the most important mass and speed limitations.

<b>JS-MD 3</b>			
<b>Limit Airspeeds:</b>			
Winch Launch $V_w$		kts	km/h
Aero-Tow $V_r$		81	150
Manoeuvring $V_A$		97	180
Rough Air $V_{RA}$		112	207
Maximum Speed $V_{NE}$		112	207
Powerplant Extended $V_{PE}$		151	280
Powerplant Extension-Retracton $V_{PO}$		135	250
Max Landing Gear Operating Speed $V_{LO}$		76	140
		97	180
		lbs	kg
<b>Maximum Mass:</b>	15m	1157	525
		1322	600
		psi	bar
<b>Tyre Pressure</b>	Main Wheel 15m	36.3	2.5
	Main Wheel 18m	50.8	3.5
	Tail Wheel 15/18m	36.3	2.5
<b>Approved Aerobatic Manoeuvres (15m and 18m):</b>			
<small>(Restrictions in Flight Manual) Positive Loops; Chandelles; Lazy Eights; Stall Turns; Spins</small>			

**Figure 2.14-1**

The placard given in Figure 2.14-1 must list the same units as the airspeed indicator. Refer to the MD10-AMM-00-001 JS-MD 3 Aircraft Maintenance Manual for the placards with other units.

Refer to MD10-AMM-00-002 JS-MD 3 Jet Sustainer Flight Manual Supplement Section 2.10 for the additional placards required when operating the Jet System.

The calculated minimum and maximum cockpit loads must be entered with a permanent marker on the cockpit placard (as illustrated in Figure 2.14-2) and must correlate with the values in the mass and balance report.

<b>Cockpit Loads: (parachute included)</b>			
	15	18	
<b>Maximum</b>	<input type="text" value="115"/> kg	<input type="text" value="115"/> kg	
<b>Minimum (i)</b>	<input type="text"/>	<input type="text"/>	kg
<b>Minimum (ii)</b> <small>Fuselage tank full</small>	<input type="text"/>	<input type="text"/>	kg
<b>Maximum Mass</b>	<input type="text" value="525"/> kg	<input type="text" value="600"/> kg	
<b>Weak link (Aero) 600kg</b>		<b>Weak link (Winch) 600kg</b>	

Figure 2.14-2

Figure 2.14-3 gives the placard to be displayed in the baggage compartment:

**BAGGAGE COMPARTMENT  
MAX LOAD: 1kg (2.2 lbs)**

Figure 2.14-3

**NOTE:** For further placards, refer to the MD10-AMM-00-001 JS-MD 3 Aircraft Maintenance Manual.



*Intentionally left blank*

## 3 Emergency procedures

### 3.1 Introduction

Section 3 provides checklist and amplified procedures for coping with emergencies that may occur.

### 3.2 Canopy jettison

To jettison the canopy pull both left and right canopy jettison latches (labelled or engraved as in the picture below) as far as possible and push the canopy upward with the latches. The Roeger hook will act as a pivot point for the emergency release.

Figure 3.2-1 illustrates the placard for canopy jettison.



Figure 3.2-1

Figure 3.2-2 illustrates the position of right-hand jettison handle in the cockpit.



Figure 3.2-2

### 3.3 Bailing out

The bailing out procedure is as follows:

1. Jettison the canopy as described in Section 3.2.
2. Push the instrument console upwards.
3. Release the safety harness.
4. To exit, lift out of the cockpit seat pan using the cockpit rim and push away from the aircraft to avoid striking the tail surfaces (and if possible try to dive underneath the wing).
5. Deploy the parachute in accordance with the manufacturer's instructions.

**CAUTION:** Due to the JS-MD 3's high maximum airspeed and because extremely high airspeeds can build up very quickly following a mid-air collision, it is recommended to use a parachute approved for speeds up to 400 km/h.

### 3.4 Stall recovery

The JS-MD 3 has a very mild stall properties recognisable by the following:

- The nose is in a higher than normal attitude relative to the horizon
- Slight buffeting approximately 2 km/h before the stall
- Airspeed indicator starts fluctuating near the stall
- A slight increase in the sink rate
- Aileron effectiveness decreases considerably

The stall recovery procedure is to release the back pressure on the control stick and move it towards the neutral position.

**CAUTION:** During stalled flight if the angle of attack is increased by further pulling back on the stick, a wing drop may occur. This asymmetric stall may result in a spin if incorrect stall recovery procedures are used.

**NOTE:** When a stall is initiated by pulling with the nose to a high pitch angle (in excess of 30° above the horizon), the nose may pitch down well below the horizon during the recovery and the altitude loss during recovery may exceed 60 m or 200 ft.

**NOTE:** When a stall is initiated with 45° bank, and the resulting roll is not prevented with the use of opposite rudder, a loss of altitude exceeding 100 m or 330 ft may ensue.

### 3.5 Spin recovery

Spin recovery is performed using the standard recovery procedures:

1. Apply rudder opposite direction to the spin rotation
2. Simultaneously release the elevator back pressure by moving the stick forward to the neutral position
3. Centralize the rudder when the rotation stops
4. Gently pull out of the resulting dive

**NOTE:** Ailerons should be kept neutral during the recovery process. (However, full aileron deflection in either direction does not have a significant influence on the recovery behaviour.)

**CAUTION:** Move flaps to Position 3 during the pull-out if the spin was commenced in flap Position 4, 5 or L to avoid exceeding  $V_{FE}$  (Maximum Flap Extended Speed).

**CAUTION:** Do not use airbrakes during the pull-out of the dive.

**WARNING:** Intentional spins with water ballast are prohibited.

Altitude loss during recovery is between 100 m and 300 m (330 ft to 500 ft) The worst recorded case required 380 m (1250 ft) with the CG in the aft position. The spin rotation speed is relatively low, typically five to six seconds per rotation by varies during spinning.

If the spin is entered with a high incident angle, the nose will oscillate in pitch during the first two rotations. After approximately one rotation, the nose will (with very aft CG positions) rise above the horizon before stabilizing in a nose down spin attitude. Pitch oscillation may continue during the spin, especially with aft CG positions.

### 3.6 Spiral dive recovery

A spiral dive may occur when:

- The aircraft terminates spinning automatically should the pilot continue applying into-spin control inputs.
- During excessive slip angles with full rudder deflection.

Indications of a spiral dive are high bank angle, increasing airspeed and a high G-loading.

Spiral dive recovery is performed by:

1. Apply aileron, co-ordinated with rudder, gently against the direction of the turn until the wings are level with the horizon
2. When the wings are level, neutralize both aileron and rudder
3. Gently pulling out of the resulting dive

**CAUTION:** During the resulting dive take care not to exceed  $V_{NE}$ .



### 3.7 Excessive sideslip recovery

An excessive sideslip may occur when the pilot applies full cross control input.

At a slip angle exceeding 20° (approximately 40° on the yaw string) rudder control forces reverse as the rudder is sucked into the wake of the stalled fin.

To recover from an excessive slip:

1. Apply opposite rudder against the direction of the yaw.
2. When balanced flight is restored, neutralize both aileron and rudder.

**WARNING:** If an excessive slip angle is not corrected with opposite rudder input, the secondary effect of yaw may cause the sailplane to roll and enter a spiral dive. It is not possible to prevent roll by applying full opposite aileron during excessive sideslip.

**CAUTION:** The rudder control input force to recover from a side slip exceeding 20° is high (approximately 20 daN) and increases if the speed is allowed to build up during the resulting spiral dive. Apply sufficient rudder input to recover from the sideslip to prevent spiral dive.



### **3.8 Engine failure – Jet turbine**

Refer to MD10-AFM-00-002 JS-MD 3 Jet Sustainer Flight Manual Supplement Section 3.2.

### **3.9 Engine Fire**

#### **3.9.1 Engine fire on the ground**

Refer to MD10-AFM-00-002 JS-MD 3 Jet Sustainer Flight Manual Supplement Section 3.3.

#### **3.9.2 Engine fire in flight**

Refer to MD10-AFM-00-002 JS-MD 3 Jet Sustainer Flight Manual Supplement Section 3.3.

## 3.10 Electrical fire

An electrical fire is very unlikely due to the protection with circuit breakers for all systems. Each battery has a fuse at the terminals and each battery supply has a circuit breaker switch on the instrument panel.

In case smoke or fumes comes from the instrument panel, take the following actions:

1. Switch off the master switch supplying the circuits.
2. If a circuit breaker “pops”, reset once only. This is most probably the faulty circuit.
3. Land as soon as possible.

### 3.10.1 Cockpit fire on the ground

The most likely cause of a cockpit fire on the ground is when beams of sunlight reflected off an open canopy are concentrated onto a surface inside the cockpit.

This is easily prevented by keeping the canopy covered when the aircraft is left unattended, or by positioning the aircraft with the nose pointing towards the sun.

In case of a fire, use an aircraft type fire-extinguisher to extinguish the fire.

**NOTE:** After any electrical emergency or fire maintenance action is required.

## 3.11 Other emergencies

### 3.11.1 Cable failure during winch launch

In case of a cable failure during a winch launch, take the following actions:

1. Immediately push the stick sufficiently forward to establish a nose-down attitude in order to regain flying speed.
2. Release cable
3. Only after adequate flying speed has been regained:
  - Extend airbrakes and land straight ahead (provided sufficient runway is available), OR
  - Use an abbreviated circuit and carry out a landing on the airfield.

**NOTE:** If the cable failed during the steepest part of the launch, it is normally necessary to lower the nose well below the horizon to regain flying speed.

If the cable fails while close to the ground, gently lower the nose and land normally.

**WARNING:** Do not open airbrakes until the airspeed exceeds the normal approach speed.

### **3.11.2 Flight with asymmetric water ballast load**

Asymmetric water ballast load may develop during flight if:

1. A main tank dump valve leaks
2. One main tank dumps water faster than that the other, due to a partial opening valve, or dumping during prolonged unbalanced flight
3. Only one main tank valve opens during water dumping

A developing asymmetry is easily recognizable due to the increased roll tendency towards the heavy wing. At low airspeed a considerable amount of aileron deflection is necessary to keep the wings level.

When a developing asymmetry is observed, take the following action to prevent full asymmetry developing:

1. If a lateral asymmetry is detected but no water was dumped during the flight, there may have been a leak from one tank. The procedure to follow is:
  - a. Start to dump water
  - b. Monitor the change in roll tendency: If the roll tendency reduces, keep dumping until symmetry is restored. Stop dumping immediately if the roll tendency worsens.
2. If a lateral asymmetry develops while dumping water, one valve might not have opened or opened partially. The procedure to follow is:
  - a. Visually check if water is dumping from both wings (the water trails can be seen below the wings near the fuselage, and at the tips in the 18 m configuration).
  - b. If both valves are dumping, keep dumping until both wings empty.



- c. If only one valve is dumping water, close dumping valves to prevent full water ballast asymmetry developing.

If the asymmetrical loading cannot be rectified, the pilot is strongly recommended to:

- Land at a suitable airport or field as soon as possible.
- Increase approach speed by 10km/h or 5kts.
- Avoid any operation near stall speeds
- Avoid turns in landing flap with airbrakes extended
- Keep the heavy wing as high as possible during the ground run. Change to the negative flap position after touch down.
- Plan the ground run to accommodate a possible ground loop towards the heavy wing.

**NOTE:** Check the dump valves before each flight.

Avoid dumping water for prolonged periods of asymmetric flight (for example slipping or skidding while thermalling). This reduces chances of asymmetric water load distribution.

### 3.11.3 Spin recovery procedure with asymmetric water ballast load

It may be possible to recover the JS-MD 3 from a spin with a significant asymmetric water ballast loading, provided correct recovery procedures are followed. The high rotation rate of approximately 120° per second may cause extended airbrakes to blank off the elevator. With airbrakes extended the spin attitude stabilizes with the nose approximately 20° below the horizon.

To recover from a spin towards the heavy wing, use the following procedure:

1. Apply full rudder opposite to spin rotation
2. Simultaneously release the elevator back pressure by moving the stick fully forward
3. Close the airbrakes
4. Move flaps to full negative position (Position 1)
5. Apply aileron into the turn
6. Centralize the controls when the rotation stops
7. Gently pull out of the resulting dive

A spin entry towards the lighter wing is unlikely and recovery is normal.

**WARNING:** Intentional spins with water ballast are prohibited and recovery with asymmetric water ballast loading may be impossible if the incorrect recovery procedure is used.

### **3.11.4 Emergency landing with landing gear retracted**

Emergency landings with the landing gear retracted are not recommended because the energy absorption ability of the spring mounted landing gear is much higher than the fuselage shell. However, if an emergency landing with the landing gear retracted is inevitable, land with the flaps in Position L. Try not to stall the aircraft more than 30 cm (1 ft) above the ground.

### **3.11.5 Ground loop**

If a landing area is too short to stop safely before the end, a ground loop may be initiated:

1. Apply maximum wheel brake to reduce energy as much as possible
2. Initiate ground loop at least 50 m or 165 ft before the end of the landing area.
3. Lower the into-wind wingtip to the ground
4. Apply rudder towards the ground loop direction and simultaneously decrease the load on the tail wheel load by moving control stick forward



### **3.11.6 Icing**

Controls may freeze up when flying in icing conditions. If ice formation is observed during flight, immediately descend below the freezing altitude level. Control surfaces should be moved continuously and airbrakes operated frequently to avoid flight control freezing.

The direct vision panel can be opened to increase visibility.

### **3.11.7 Emergency landing on water**

During water landing tests with landing gear retracted, it has been shown that aircraft fuselage can submerge completely. The following procedure is recommended for an emergency landing on water:

1. Dump all ballast
2. Make a radio call
3. Extend the landing gear
4. Undo the parachute harness during the downwind leg
5. Ensure safety straps are tight
6. Try to land parallel to the shore and against the wind.
7. Close water dump valves before touch down
8. Touch down with gear extended and speed as low as possible
9. At touch down point use left arm to protect your face against possible canopy fracture
10. After touch down undo belt harnesses

If the sailplane has sustained no damage to the water tanks, it may stay afloat for a long period. Swimming may be the only option when the airframe starts sinking.

## 4 Normal operating procedures

### 4.1 Introduction

Section 4 provides checklist and amplified procedures for the conduct of normal operations. Normal operations associated with optional systems can be found in Section 9.

### 4.2 Rigging and de-rigging

#### 4.2.1 Rigging

The JS-MD 3 can be rigged by three people without rigging aids or by two people if a fuselage cradle and wing stands are available.

#### Wing rigging

1. Check that there is adequate ground clearance to extend the landing gear. When rigged, the assembled aircraft might be too heavy to lift to extend the landing gear.
2. Ensure the rubber water drain plugs are inserted in the wing roots in front of the forward lift pin.
3. Clean and grease all pins and matching bushes including main pins.
4. Unlock both airbrakes using the airbrake locking wrench.
5. Set the flap handle in Flap Position 2 or Position 3 and the control stick to the centre position.
6. Close the water valve in the cockpit.
7. Ensure the self-aligning bushes in the main ribs of both wings are aligned correctly.

8. Insert the right spar end into the fuselage with the flaperon in the neutral position and the dihedral angle approximately correct.
9. Insert the left spar end into the fuselage, also with the flaperon in the neutral position and the dihedral angle such to slide into the self-aligning bush of the other wing.
10. Insert the main pin when the wings are fully in.
11. Secure the main pin by rotating the pin into the spring- loaded locks pins.
12. Ensure the tail is lifted of the ground with sufficient clearance for the tail wheel to extend. Extend and lock the landing gear and lower aircraft onto the wheel.
13. Ensure the 18 m tip rubber water drain plugs are inserted (18 m wing tips roots).
14. Pull wingtip locking lever fully back and slide wingtip beam into main wing. Push the wingtip locking lever forward and ensure it locks positively by pushing the lever over-centre.

**CAUTION:** The flaperon sandwich can be damaged if excessive force is used and should be handled with care.

**WARNING:** Never grease the water drain valve, the rubber based seal may be damaged and become detached from the valve-body.

### Mount tailplane

1. Clean the tailplane pins and bushes
2. Clean and lubricate the pitot-static auto-connectors. Ensure the O-rings are serviceable.
3. Slide the tailplane onto the fin. Take care that the elevators are sliding into the elevator auto-coupler.



4. Ensure the Mylar edge on the tailplane does not snag on the fin.
5. Screw the tailplane main bolt into position, using the hex socket key tip of the JS rigging tool.

**CAUTION:** Take care not to over-tighten the tailplane front attachment bolt. (Hand-tight only, max. 1 Nm torque.)

### **Install Auxiliary items**

1. Insert the batteries into position in the luggage compartment behind the seat headrest. Secure the batteries in position with the battery retainers.
2. Check the battery fuses / circuit breakers on the battery connector boxes.
3. Install the pitot-static and total energy tube and test gently for test leaks.
4. Seal the wing-fuselage junctions, wing-wingtip junctions, and the fin-tailplane junctions with tape.
5. Perform the daily inspection, including positive control check on all controls.

### **Refuelling – TJ-42 Jet Sustainer**

Refer to MD10-AFM-00-002 JS-MD 3 Jet Sustainer Manual Section 4.10.3.

**CAUTION:** The convex shape of the canopy can act as a lens and is a fire hazard when the canopy is left open in the sun.

#### 4.2.2 De-rigging

1. Ensure the non-expendable tail tank is drained of water.
2. Remove Auxiliary items
3. Remove the main batteries. Lock the battery retainers back in position.
4. Remove the total energy tube and pitot static tubes as well as temporary equipment (Logger etc.) Install the "Remove before flight"-cover in the multi probe receptacle.
5. Remove the sealing tape on wing-fuselage junction, wing-wing tips junction and tailplane-fin junction.

#### Retracting the undercarriage

1. Lock the tail wheel in the down position by inserting the optional locking pin, or ensure the taildolly is fitted before retracting the landing gear.
2. Roll the aircraft into the fuselage dolly. (The gear doors should be approximately 5 cm (2 inches) from the ramp end.)
3. Lift the ramp until the main wheel is at approximately 5 cm (2 inches) off the ground.
4. Retract the main wheel.

**CAUTION:** Permanent damage to the retractable tail wheel mechanism will result if the landing gear is retracted with the tail wheel on the ground.



### Removing the tailplane (horizontal stabilizer)

1. Unscrew the front attachment bolt using the hex socket key tip of the JS rigging tool.
2. Slide the tailplane forward. Take care to move the tailplane forward evenly so as not to damage the elevators or the elevator auto-coupler.
3. Screw the front attachment bolt back in the fin (not applicable if a captive bolt is fitted).

### Removing the wings

1. Unlock the airbrakes from the cockpit
2. Set the flap handle in Position 2 or Position 3 and move the control stick to the centre position.
3. Pull wingtip locking lever fully back and slide wing-wingtips out of the inboard section. Secure the wingtips in the trailer.
4. Insert the tip rigging handle in the tip spar box.
5. Lift the wings at the tips until the main pin can rotate. Rotate the wing pin out of the locked position while pulling back the lock pin.
6. Remove the main pin.

**CAUTION:** Maintain the dihedral angle while removing the wings. The fuselage shell may be damaged if the correct angle is not maintained.

7. Pull the left wing out of the fuselage spar box – secure the wing in the trailer
8. Pull the right wing out of the fuselage spar area – secure the wing in the trailer
9. Lock both airbrakes, using the JS Airbrake lock tool.



10. Push the fuselage into the trailer

**NOTE:** To avoid loading the airbrake caps, do not leave the airbrakes locked for long periods (either rigged or de-rigged). The airbrake locking tool can be used for temporarily locking the airbrakes for maintenance or transportation, and the airbrakes should be unlocked when maintenance or transportation is complete

**CAUTION:** Take care not to damage the unlocked airbrakes when using a trailer with a hinged top (e.g. Cobra, SWAN, Comet etc.). It is likely that damage will result if the airbrakes are partially or fully open when lifting the trailer top.

### 4.3 Daily inspection

After the aircraft has been rigged and always before the first flight of the day, the aircraft must be inspected carefully to ensure its airworthiness.

The following inspection is essential for flight safety:




Figure 4.3-1



### 4.3.1 Forward fuselage

1

Check functionality of the nose release hook

### 4.3.2 Cockpit

2

1. Ensure the canopy is clean
2. Check the canopy emergency release mechanism: pull back both jettison latches slowly. A detent should be feelable once the mechanism reaches the end of the normal opening and the emergency release is engaged. Care should be taken not to release the canopy completely without having assistance to prevent it from falling.
3. Ensure that the main pins are secured properly.
4. Ensure the proper connection of flaperon and airbrake system:
  - With the control stick in the neutral position and the flap lever in position 3, the flaperon must be flush with the trailing edge at root rib,
  - Airbrakes must lock properly and open evenly
5. Ensure the operation of the rudder pedals, and:
  - Move the rudder pedals fully forwards and backwards to check the rudder cables for signs of fraying, kinks and wear especially near the S-tube exits.
  - Perform a visual check on the rudder pedal retention nuts by checking that they are securely in place.
  - Ensure pedals lock positively in the desired setting under load.

6. Ensure the operation of the water system (main and tail tank valves)
7. Ensure that charged batteries are correctly installed and connected
8. Ensure that the oxygen bottle is properly secured
9. Ensure that the cockpit is clean and all foreign matter is removed
10. Ensure the condition and operation of the safety belts, especially where they pass through the seat back

#### **4.3.3 Landing gear**

**3**

1. Visually inspect the mechanism and locks
2. Check the condition of the shock absorbing rubbers
3. Check the tyre pressures –
  - Main wheel - 15 m: 2.5 bar (36.26 psi)
  - Main wheel - 18 m: 3.5 bar (50.76 psi)
  - Tail wheel: 2.5 bar (36.3 psi)
4. Check the tyre slip mark position and tyre condition
5. Check the condition of the wheel doors hinges and closing springs or bungee cords
6. Check that the CG hook manual and automatic operation works properly. Accumulated dirt or mud may lead to improper functioning of the release hook.
7. Check that the water drain orifice behind the landing gear box is clear.

#### **4.3.4 Wings**

**4**

1. General condition - check for evidence of damage to the surface finish or structural damage, pressure marks and cracks.

2. Check that the water drain orifices at the wing root and tip are clear.
3. Check the airbrakes for functioning and locking. Check for water or foreign objects in the airbrake boxes.
4. Check that the outer wing panel is properly locked without play.
5. Check that the flaperons move freely with no hinge play. Perform a positive control check on the inboard and outboard flap.
6. Check that wing tip wheels are in good condition – the clearance between the flap trailing edge and the ground in positive flap with maximum aileron deflection must be at least 10 mm. Check that wheels are attached positively to the wing.
7. Check that control surface gap seals are installed and properly adhered to the wing recesses.
8. Check that the NACA ducts on the lower surface of the flaperons are clear.
9. If the bug wiper system is installed, perform the checks given in Section 7.12.4
10. If flying with water ballast:
  - Check before filling if all the rubber seals on the dump valves are in position, and that all valves are operating correctly.
  - Check the dump rate of the main tanks with the filler caps installed. Ensure that the dump rates of the wings are equal and faster than the dump rate of the tail tank.

#### 4.3.5 Fuselage

5

1. General condition - check for evidence of damage to the surface finish or structural damage, pressure marks and cracks.
2. Check that the static pressure ports on the fuselage boom are unobstructed.

3. Check that the tail wheel is sufficiently inflated.
4. Check that the water drain orifice in front of tail wheel is not obstructed.

#### **4.3.6 Tail section**

**6**

1. General condition - check for evidence of damage to the surface finish or structural damage, pressure marks and cracks.
2. Check that the Total energy and pitot probe receptacles are clear. Drain all possible water from the receptacle (if the probe was left in position during rain) by removing the tailplane and rotate.
3. Ensure the total energy and pitot probes are installed correctly and pushed all the way in. The pitot probe is positioned on the righthand tailplane tip. Check instrument functionality by carefully blowing on the multi-probe's Pitot-, Static and TE ports.
4. Check that the expendable tail tank has no water before filling, by blowing into the filling port with the dump valve in the open position with the vent holes blocked.
5. Check the vertical tail tank valve operation. Check that the dump rate of the tail tank exceeds 1 litre per minute.
6. Check that the tank vent holes on the left-hand side of the fin are unobstructed.
7. Check that the amount of water in the vertical tail fin water ballast tank is correct in relation to wing water ballast and cockpit load.
8. Check that the horizontal stabilizer is properly installed without free play.
9. Check that the control surface gap seals are installed and properly adhered to the stabilizer and fin recesses.

**CAUTION:** Blowing into the Pitot, Static, and Total Energy probes may cause permanent damage to instruments if performed incorrectly.

#### 4.3.7 Jet sustainer

7

Inspect the jet system in accordance with MD10-AFM-00-002 JS-MD 3 Jet Sustainer Flight Manual Supplement Section 4.

## 4.4 Pre-flight check

- Daily Inspection - Performed
- Control Systems - Functional check, positively connected, free movement and no play
- Expendable Tail Tank (bottom) - Valve opening positively checked
- Non-expendable Tail Tank (top) - Ensure empty or correctly loaded for CG range
- Water Ballast System - Check operation and proper sealing of valves and vents unobstructed
- Weight and Balance - Trim weight, water ballast (tail and wing tanks), minimum and maximum cockpit load within calculated limits
- Total Energy Tube - Fitted and connection properly sealed, indication ok
- Altimeter - Set correctly (QNH / QFE / QNE)
- Radio - Set to airfield frequency, check operation
- Other instrumentation - Checked, normally indicating zero
- Backrest - Adjusted
- Rudder pedals - Adjusted and locks positively in all settings.
- Documentation - Complete and valid
- Landing gear - Locked with no play

## 4.5 Normal procedures and recommended speeds

### 4.5.1 Winch Launch procedures

Winch launching is performed using the CG hook in front of the main wheel.

With a slow-accelerating winch, good aileron control is achieved using Flap 3. With a gentle to strong headwind Flap 4 may be used from the start.

Allow the aircraft to get airborne in the 2-point position (main wheel and tail wheel just touching). As the speed builds up, gently rotate into the full climbing attitude. Change to flap setting 4 when the aircraft is established in the full climbing attitude.

Winch launch speed table	Airspeed km/h / (kts)
Recommended winch launch airspeed (No water ballast)	130 km/h (70 kts)
Recommended winch launch airspeed (MAUW)	140 km/h (76 kts)
Minimum safe winch launch speeds without water ballast	115 km/h (62 kts)
Minimum safe winch launch speeds with water ballast	125 km/h (67 kts)
Maximum winch launch speed ( $V_w$ )	150 km/h (81 kts)

**Table 4.5-1**

To release, pull the yellow release handle all the way. Releasing under tension is not recommended, as this may cause overruns on the winch drum.

**NOTE:** With the CG is the aft position the launch should be commenced with the trim in the full forward setting.

**WARNING:** With the CG is the aft position and a fast acceleration, the glider will automatically rotate into the climb. Full pitch control is restored at 120km/h in this condition.

**WARNING:** Retracting the landing gear during the winch launch is not permitted.

**WARNING:** Downwind winch launches jeopardise the safety of the launch significantly and should be avoided.

**WARNING:** Winch launch with water ballast should only be attempted with a powerful winch and into wind.

**WARNING:** Release immediately if the wings cannot be kept level during the ground run.



#### 4.5.2 Aerotow launch procedure

Aerotows are performed using the nose release hook. Refer to Section 2.12 for rope lengths.

Initiate the ground run in negative flap (Flap setting 1). This will increase aileron efficiency at low speeds. In a crosswind take-off, keep the stick aft during the initial acceleration. This prevents the aircraft weather-cocking into wind.

As soon as positive aileron control is available, set the flap to the setting indicated in Table 4.5-2.

Aerotow speed table	Flap setting	Airspeed km/h / (kts)
Recommended aerotow speed (No water ballast)	4	130 km/h (70 kts)
Recommended aerotow speed (MAUW)	4	140 km/h (76 kts)
Minimum safe aerotow speed (No water ballast, calm conditions)	4	115 km/h (62 kts)
Minimum safe aerotow speed (MAUW, calm conditions)	4-5	125 km/h (67 kts)
Minimum safe aerotow speed (MAUW, turbulent conditions)	3-4	140 km/h (76 kts)
Maximum Aerotow speed ( $V_T$ )	3	180 km/h (97 kts)

**Table 4.5-2**

Retracting the landing gear on aerotow is not recommended.



To release, pull the yellow release handle all the way. If the low tow position is used, it is recommended to release only after moving into the slipstream of the tow plane - the swirling rope end may cause damage to the aircraft when releasing in the low tow position.

**NOTE:** With the CG is the aft position the launch should be commenced with the trim in the full forward setting. Adjust trim in during tow as required.

### **4.5.3 Engine operation procedures**

#### **4.5.3.1 Engine start, run-up, taxi procedures**

Refer to MD10-AFM-00-002 JS-MD 3 Jet Sustainer Flight Manual Supplement Section 2.8

#### **4.5.3.2 Self-launch**

Not approved for the Jet sustainer version.

### **4.5.4 Flight**

The JS-MD 3 offers exceptionally good flying characteristics, handling and manoeuvrability.

#### **4.5.4.1 Thermalling**

The optimum flap setting for thermalling is Position 4 or 5.

Flap setting 4 is the normal thermalling flap setting. The optimum thermal speed at maximum loading is 110 to 115 km/h (57 to 62 kts).

When the thermals are very rough it is recommended to fly slightly faster (120 km/h / 65 kts).

Flap setting 5 gives best results in smooth thermals where minimal centring is required. At maximum weight with this flap setting, the best speed to fly is 108 to 110 km/h (58 to 60 kts).

#### 4.5.4.2 Inter thermal cruise

To optimise the glide performance, it is important to select the proper flap according to weight and cruise speed. The flaps modify the airfoil's camber, maintaining laminar flow over a wide range of lift coefficients. For every speed and weight combination, there is an optimum flap setting for maximising the glide angle.

The following table gives the optimum flap setting as a function of speed and weight.

Flap		4	3	2	1
Deflection		+13.5°	+5°	0°	-3°
Configuration	With no water ballast	90 - 110 km/h 49 - 59 kts	110- 120 km/h 59 - 65 kts	120- 180 km/h 65 - 97 kts	180 km/h - $V_{NE}$ 97 kts - $V_{NE}$
	With max water ballast	105 - 25 km/h 57 - 67 kts	125- 140 km/h 67 - 76 kts	140- 200 km/h 76 - 108 kts	200- $V_{NE}$ km/h 108 kts - $V_{NE}$

**Table 4.5-3**

**CAUTION:** Observe airspeed limits versus altitude to avoid exceeding  $V_{NE}$  and  $V_{FE}$ .

#### **4.5.4.3 Inflight Engine Start Procedures**

Refer to MD10-AFM-00-002 JS-MD 3 Jet Sustainer Manual Section 4.9.

#### **4.5.4.4 Engine operation in flight**

Refer to MD10-AFM-00-002 JS-MD 3 Jet Sustainer Manual Section 4.

#### **4.5.4.5 Inflight engine stop procedure**

Refer to MD10-AFM-00-002 JS-MD 3 Jet Sustainer Manual Section 4.

#### **4.5.4.6 Lightning**

The JS-MD 3 is not approved for flight where lightning strikes may occur.

**WARNING:** Flights in conditions conducive to lightning strikes must be avoided.

### 4.5.5 Approach

The circuit can be flown with flap set to Setting 3 to 5 (+5° to +16.7°). On final approach for landing the flaps can be changed to Position L (+20°) for a shorter landing with lower touch down speed. Due to high aerodynamic forces, flaps may not be extended to setting L above 160km/h (or 86kts).

Water ballast should be dumped prior to landing. Refer to Section 3.11.2 for asymmetric loading.

Ensure the landing gear is down and locked and verified as such before commencing final approach. The landing gear is lowered when the cockpit handle is moved to the forward position.

Table 4.5-4 gives the recommended airspeeds for the approach:

Minimum Recommended Approach Speeds: (Various Approach Types)	Loading configuration	
	Minimum Weight	Max All-Up Weight
Calm conditions, No airbrakes	105 km/h 57 kts	120 km/h 65 kts
Calm conditions, airbrakes fully extended	110 km/h 59 kts	125 km/h 67 kts
Approach in rain, No airbrakes	115 km/h 62 kts	130 km/h 70 kts
Approach in rain, Full airbrakes	120 km/h 65 kts	135 km/h 73 kts
Strong crosswind, Flap setting 3, full airbrakes	120 km/h 65 kts	135 km/h 73 kts

**Table 4.5-4**



At maximum weight with the airbrakes fully extended and at 117 km/h (63 kts), the approach angle is approximately 1:6 (in calm conditions). Any increase in airspeed increases the approach angle significantly and at  $V_{NE}$  without water ballast the descent angle is approximately 45°.)

**CAUTION:** When on final approach, do not change to more negative flap settings (for example, from Setting L to Setting 4) without sufficient airspeed as the resulting loss of lift will cause a significant loss of height.

**NOTE:** Always lower the landing gear, especially in the case of an emergency landing.

**NOTE:** Side-slipping the JS-MD 3 on final approach is not recommended as this is an inefficient method to increase the sink rate. However, the aircraft can be side-slipped up to a speed of 203 km/h (110 kts). Partial water ballast has no noticeable effect on the flying characteristics during a sideslip. Airspeed indication may under-read at yaw angles exceeding 20°.

**WARNING:** When executing a sideslip exceeding an angle of 20°, the control force gradient becomes negative i.e. the rudder will be aerodynamically pushed against the rudder stop. This can be corrected by applying opposite rudder. **Refer to Emergency section for the recovery procedures of an excessive sideslip.**

**NOTE:** Landing in Flap Setting 2 or Setting 1 is strongly discouraged due to the increased stall speeds.

**NOTE:** In the landing configuration with aft CG the maximum trim speed is  $0.84 V_{FE}$ .

#### 4.5.6 Landing

The correct attitude for landing is the two-point attitude with the main wheel and tail wheel making contact with the ground simultaneously.

The hydraulic wheel brake is activated by squeezing the trigger on the control stick. Ensure that the wheel brake is not applied before touch down.

After touchdown the wheel brake can be activated. It is recommended to select negative flaps (Setting 1) after touch down. This reduces the risk of nose-over when braking hard, reduces the chances of damaging the flaperon trailing edges on uneven surfaces and improves aileron control at slow speeds.

Whilst slowing down, and it is no longer possible to keep the wings level, centralise the ailerons and brake positively to stop completely. This minimises wear on the tip skid/wheel and reduces the risk of damaging the flaperons.

Safe landing in cross-winds up to 30 km/h (16 kts) is possible due to polyhedral wing shape allowing high bank angles during touch down:

1. Use Flap setting 4 for moderate crosswinds and Setting 3 for strong crosswinds (exceeding 25 km/h or 14 kts).
2. Align the aircraft nose with the runway centreline using the rudder.
3. Lower the into-wind wing sufficiently to overcome drift.
4. Keep the into-wind wing lowered until coming to a complete stop.
5. Change to Flap setting 1 after touch down.

#### 4.5.7 Flying with water ballast

The water ballast system allows the weight of the aircraft to be increased to achieve higher wing loadings. The water tanks are integral in the wings.

In the 15 m configuration water is only carried in the inboard section. Each inboard wing tank holds approximately of 78 litres of water.

In the 18 m configuration water is also carried in the wingtips. Each wing tip additionally carries 17 litres of water.

There are two water ballast trim tanks in the fin of the JS-MD 3. The water ballast in the bottom tail tank can be dumped and is connected to the main tank valves and will dump simultaneously with the inboard main tanks. This tank can be used to offset the centre of gravity change due to the water ballast in the main inboard wing tanks.

To offset the forward centre of gravity change due to water in the main wing tanks (inboard), the expendable ballast tail tank must be filled according to the graph given in Figure 4.5-1.


The top tank ballast is not expendable and can be used to trim the centre of gravity position for pilot weight. Table 4.5-5 gives the tail tank capacity for the JS-MD 3.

<b>Water ballast capacity (liters)</b>	<b>15 m</b>	<b>18 m</b>
Main inboard wings	78x2 liters	
Wing tips	0	17x2 liters
Expendable tank capacity	5.8 liters	
Top tank capacity (non-expendable tank)	8.9 liters	
Fuselage tanks (if fitted), (no fuselage water-tanks when jet sustainer is fitted)	0	22.2 liters
<b>Total water capacity</b>	170.7 liters	226.9liters

**Table 4.5-5**



Figure 4.5-1 indicates the expendable water quantity required to balance the water in the main inboard wing tanks.



**Figure 4.5-1**

**NOTE:**

As a conservative approximation, add 1 litre of water in the bottom tail tank for every 30 litres of water in the main inboard wing tanks.

**WARNING:**

The tail tank should always be filled based on the CG calculation as described in Section 6.4. Under no circumstances is it permitted to fly with the CG aft of the rear limit.

**CAUTION:**

The filler caps must always be locked finger tight only. Excessive torque may damage the cap's edges.

#### 4.5.7.1 Filling procedure

1. Determine the quantity of water ballast to be carried. The quantity of water ballast in the tail is calculated using the graph in Figure 4.5-1.
2. Determine the quantity of water to be loaded in each tank. In the 18 m configuration the tips **must** be filled if water is carried in the main tanks. If tanks are partially loaded water must be loaded in the following sequence:
  - i. 18 m tips (if fitted)
  - ii. Main wing tanks
  - iii. Fuselage tank (if fitted)
3. Open the dump valve in the cockpit, and ensure the expendable tail tank is empty by following the procedure given in the daily inspection check list.
4. Close the dump valve in the cockpit.
5. Fill the 18 m tips (if fitted). Filling can be done through the dump valve, using filling equipment allowing a maximum of 0.1bar pressure.
6. Fill the main tanks via the filler caps on the top surface.
7. The expendable tail tank can be filled using the bottom filling port on the right hand side of the fin. Ensure that the quantity water in the expendable tank is in relation to the quantity of water in the main tanks.
8. Fill the non-expendable tail tank as follows:
  - Calculate the quantity of ballast for the non-expendable tank using the calculations explained in Section 6.4.
  - Seal the dump holes (3mm holes on right hand side of fin) with a sealing tape to up to the required level.



- Add water ballast using the top filling port (top one) on the right hand side of the fin.

#### **4.5.7.2 Dumping procedure**

1. Open the valves by shifting the dump valve lever forward and down. The combined dump rate of the main tanks are approximately 60 litres per minute. The dump rate will slow down with approximately 20% of water left .
2. Visually check if water is dumping from both wings (the water trails can be seen below the wings near the fuselage, and at the tips in the 18 m configuration). In case any valves are not dumping, valves must be closed immediately to prevent development of an asymmetry condition.
3. To dump the ballast only partially, the inboard wings must be dumped first. This is achieved by moving the damp valve lever to the centre position.
4. If progressively increased aileron deflection is required to maintain bank angle while dumping water, the water is probably dumping unevenly. Refer to Section 3.11.2 for details on asymmetrical flight procedures.
5. If more nose-down trim is required after dumping water ballast, the likelihood exists that the expendable tail water ballast has not been dumped. In this case avoid flying at speeds near the stall.
6. Allow sufficient time to completely dump all water before landing. (Approximately five minutes is required.)

**NOTE:** Increase tyre pressure up to 3.5 bar (or 50.8 psi) when flying fully loaded in 18 m configuration.


**CAUTION:** Use clean water without any additives to avoid damage to the structure and rubber seals.



- WARNING:** Residual air may create undue pressure in flights with partially loaded or empty tanks; therefore, check that breather holes of the wing- and fin tanks are always open.
- WARNING:** Never apply more than 0.1 bar of water pressure (filling funnel height no more than one metre above the wing) because of possible damage to the structure.
- WARNING:** Ensure both wing tanks are filled with equal amounts of water to prevent a wing dropping on take-off.
- WARNING:** Check for the correct dumping sequence. The tail tank must finish dumping before the main wing tanks to ensure safe shifting of CG.
- WARNING:** The wing tips must be filled with water ballast if the main tanks or fuselage tanks are filled (even partially filled)
- WARNING:** No tail ballast compensation is required for water loaded in the 18 m tips. The CG moves approximately 6mm rearwards when filling the 18 m tips.
- WARNING:** Use of water ballast is limited to non-freezing flight conditions. Do not use water ballast for prolonged flights below 0 °C (32 °F).
- WARNING:** Do not use any lubricant (grease or petroleum jelly) or wax to seal any water valves not sealing properly. Most lubricants affect the rubber seal and may result in the seal detaching from the valve unit.


### 4.5.8 High altitude flight

At higher altitudes the Air Speed Indicator will indicate values lower than the true airspeed due to the lower air density. This does not influence loads on the structure but does mean that the colour markings on the Air Speed Indicator are not correct at high density altitude. As flutter depends upon true airspeed, the maximum allowable airspeed must be reduced at high altitudes. Figure 4.5-2 gives the  $V_{NE}$  as function of altitude for both the 15 m and 18 m configurations.



**Figure 4.5-2**

The placard given in Figure 4.5-3 must list the same units as the airspeed indicator.



**Figure 4.5-3**

**WARNING:** The aircraft is not approved for flights above 9000 m (30000 ft) above mean sea level.

**Flight tests for Type Certification were only conducted to 14 000 ft AMSL.**

**CAUTION:** At higher altitudes the true airspeed (TAS) is higher than the Indicated Airspeed (IAS). Reduce the indicated airspeed to compensate for the effect of high altitude.



#### **4.5.9 Flight in rain**

When flying in rain a decrease in glide performance is expected. The airfoil is specially designed not to have any loss in lift when contaminated and the stall speed is relatively unaffected by rain and bugs. However, it is recommended to increase the landing speed by at least 10 km/h (or 5 kts) to compensate for turbulence and descending air often associated with rain. The direct vision panel can be opened to increase visibility.

See Section 4.5.5 for the recommended approach speeds associated with flight in rain.

#### 4.5.10 Using bug wipers in flight

The operation of the bug wipers in flight depends on the winder system installed. Refer to the instructions of the winder manufacturer for details on the operation. The following basic rules apply.

Ensure sufficient battery capacity is available to perform the cleaning operation and select the correct battery source for the winders.

Cleaning can be performed in level flight or during climbing, as long as airspeed between 100 km/h and 120 km/h (54 kts and 65 kts) is maintained. The aircraft should be flown without excessive slipping or skidding.

If the wings are allowed to get too contaminated, the wiper might get stuck at an area. The application of Teflon-based polish before flight will assist in preventing this problem. It may be attempted to run the wiper over the sticky part (if possible) until the surface is smooth.

**CAUTION:** Do not operate the bug wipers in very turbulent conditions or outside of the tested speed band – the bug wiper may be thrown off the wing.

**CAUTION:** Bug wiper operation in uncoordinated flight attitude may result in the wiper becoming unstable. Ensure the yaw string is straight, especially when wiping the inner wing whilst turning.



#### 4.5.11 Aerobatics

The entry speeds and recommended maximum G-loading for approved aerobatic manoeuvres is given in table below.

Aerobatic entry speed	Flap setting	Entry speed	G-loading
Lazy Eight	3	180 km/h (97 kts)	3
Chandelle	3	150 km/h (81 kts)	2
Steep turn	3	150 km/h (81 kts)	3
Positive loop	3	200 km/h (108 kts)	3.5
Stall turns	3	200 km/h (108 kts)	3

**Table 4.5-6**

#### 4.5.12 Flight over built up areas

Use of the engine system over built up areas below 300 m (1000 ft) is strongly discouraged due to possible noise limitation.



## **5 Performance**

### **5.1 Introduction**

Section 5 provides approved data for airspeed calibration, stall speeds, take-off performance and non-approved further information.

The data in the charts has been computed from actual flight tests with the sailplane in good condition and using average piloting techniques.

## 5.2 Approved data

### 5.2.1 Airspeed indicator calibration

During airspeed calibration tests, the airspeed indicating system was found to be accurate to within 2 % over the whole range from  $V_{S0}$  to  $V_{NE}$ . Figure 5.2-1 gives the airspeed correction chart.




Figure 5.2-1: ASI calibration chart

## 5.2.2 Stall speeds

The stall speeds (IAS) for the 15 m and 18 m configurations of the JS-MD 3 are given in Table 5.2-1 and Table 5.2-2.

Table 5.2-1 gives the stall speeds for the JS-MD 3 (15 m configuration) with Airbrakes retracted and CG in the foremost position:

### 15 m configuration (forward CG)

Gross weight	415 kg / 915 lbs		525 kg / 1157 lbs	
Flap Setting	Minimum Achievable Speed (IAS), CG fwd.		Minimum Achievable Speed (IAS), CG fwd.	
L (20°)	78 km/h	42 kts	86 km/h	46 kts
5 (16.6°)	79 km/h	43 kts	88 km/h	48 kts
3 (5°)	87 km/h	47 kts	95 km/h	51 kts
1 (-3°)	91 km/h	49 kts	98 km/h	53 kts

Table 5.2-1

Table 5.2-2 gives the stall speed with Airbrakes retracted and CG in the foremost position in the 18 m configuration:

### 18 m configuration (forward CG)

Gross weight	430 kg / 948 lbs		600 kg / 1323 lbs	
Flap Setting	Minimum Achievable Speed (IAS), CG fwd.		Minimum Achievable Speed (IAS), CG fwd.	
L (20°)	74 km/h	40 kts	88 km/h	48 kts
5 (16.6°)	74 km/h	40 kts	83 km/h	46 kts
3 (5°)	81 km/h	44 kts	89 km/h	48 kts



1	(-3°)	89 km/h	48 kts	97 km/h	52 kts
---	-------	---------	--------	---------	--------

**Table 5.2-2**

With the flying centre of gravity in the forward positions, the elevator may not be able to produce a sufficiently high angle of attack to completely stall the wings in positive flap settings. In this case, the stall speeds are defined by the minimum achievable speed for the specific flap setting.

The stall speed in all flap settings is increased by approximately 5 km/h with the airbrakes extended. The landing gear position has no measurable influence on the stall speeds.

### 5.2.3 Take-off performance

Not applicable to self-sustaining glider.

### 5.2.4 Additional information

#### 5.2.4.1 Turbulators

On the lower surface of the flaperons there is a line of blow holes supplying air by NACA ducts. It is necessary to keep these holes and ducts clean for optimum performance. The blow holes force the boundary layer transition from laminar flow to turbulent flow in flap setting 1 and 2. If the boundary layer control is not working properly, a whistling sound can be heard when changing to flap setting 1 and 2.

**WARNING:** Turbulator tape is fitted to the tailplane and rudder and it is essential for both the performance and control of the aircraft. Flight without tailplane turbulators is not allowed as it might result in a reduction in pitch authority. See the MD10-AMM-00-001 JS-MD 3 Aircraft Maintenance Manual for the correct location of the turbulator tape.



## **5.3 Non-approved information**

### **5.3.1 Demonstrated crosswind performance**

The JS-MD 3 has very good crosswind handling characteristic due to its polyhedral wing shape allowing high bank angles during touch down.

The maximum demonstrated crosswind components are:

During aerotow: 25 km/h (14 kts)


During winch launch: 25 km/h (14 kts)

During landing: 30 km/h (16 kts)

**NOTE:** See Section 4 on Approach and Landing for more information on landing in crosswinds.

### 5.3.2 Flight polar

Figure 5.3-1 illustrates the calculated polar for the JS-MD 3 in the 15 m and 18 m configurations for two wing loading cases:





 <p>M+D FLUGZEUGBAU</p>	<p><b>JS-MD 3 Aircraft Flight Manual</b></p>	<p>MD10-AFM-00-001 Issue: 00.21 Date: 13.09.2017</p>
---	--	--

**Figure 5.3-1**

### **5.3.3 Noise data**

Not applicable to the pure sailplane or self-sustaining aircraft.

## 6 Weight and balance

### 6.1 Introduction

Section 6 contains the payload range for the JS-MD 3 sailplane within which it can be operated safely.

The procedures for weighing and establishing the permitted payload range is given in MD10-AMM-00-001 JS-MD 3 Aircraft Maintenance Manual, including:

- Weighing procedures
- CG calculation formulas
- Calculation of minimum and maximum cockpit loads

### 6.2 Weight and balance record

The Weight and Balance Record summarizes the results of weight and balance calculations and gives the maximum and minimum allowable pilot weights for the aircraft.

The calculated minimum and maximum cockpit loads (as entered on the cockpit placard) must correlate with the values in the mass and balance report and the latest entry in the logbook weight and balance section.

**NOTE:** The data presented on the Weight and Balance Record (Table 6.2-1) is only valid for the Serial number entered on the form.

Weight and Balance Record Sheet						
Date	Empty weight (M <sub>EMPTY</sub> )	Empty CG position (X <sub>CG</sub> )	Permitted pilot weights		S/N: <i>36 MD011</i>	
			Min	Max	Approved	
					Date	Signed
<i>15m</i> 20.04.	<i>289,6</i>	<i>601,2</i>	<i>70</i>	<i>115</i>	<i>20.04</i>	<i>[Signature]</i>
<i>18m</i> 20.04	<i>320,8</i>	<i>598,8</i>	<del><i>105</i></del> <i>74</i>	<i>115</i>	<i>20.04</i>	<i>[Signature]</i>

Table 6.2-1

For the calculation of the permitted maximum and minimum pilot weight refer to formulas given in the MD01-AMM-00-001 JS-MD 3 Aircraft Maintenance Manual.

## 6.3 Permitted payload-range and CG envelope

The JS-MD 3 CG envelope is based on the allowable flying mass and CG ranges given in Section 2.5 and Section 2.6.

Care must be taken that the CG stays within the allowable limits. The following loads have an effect on the CG position:

- Pilot
- Cockpit ballast (removable)
- Water ballast - main tank (and tip tanks in 18 m configuration)
- Water ballast – expendable tail tank
- Non-expendable tail tank
- Baggage
- O<sub>2</sub> bottle
- Fuselage Water ballast (top & bottom tanks)
- Fin Ballast

To allow the pilot to achieve the desired CG position, adjustment possibilities are the cockpit ballast, lead tail ballast and water in the non-expendable tail tank (top fin tank).

The expendable water tank in the fin (bottom fin tank) is used to offset the centre of gravity change due to the water ballast in the main wing tanks. No change in the set CG is expected during dumping when this tank is correctly loaded.

Figure 6.3-1 and Table 6.3-1 give the maximum mass and the moment arms of the various variable loads. The moment arms are measured from the datum, with the sign convention:




Figure 6.3-1

#		Loading point	Max Mass		Moment arm	
			kg	lbs	mm	inch
1	$M_{\text{Pilot}}$	Pilot (with parachute)	115	253.5	-645	-25.4
2	$M_{\text{Cockpit}}$	Cockpit ballast (removable)	20	44.1	-450	-17.7
3	$M_{\text{O}_2}$	O2 bottle AL248	2	4.4	0	0
4	$M_{\text{Bag}}$	Baggage compartment	1	2.2	150	5.9
5	$M_{\text{WingM}}$	Water ballast - main	156	343.9	~247	9.7
6	$M_{\text{WingT}}$	Water ballast – tip (18 m)	35.8	78.9	480	18.9
7	$M_{\text{FusT}}$	Fuel tank - top	6.8	15	500.4	19.7
8	$M_{\text{FusB}}$	Fuel tank – bottom	15.4	34	852.5	33.6
9	$M_{\text{Tail1}}$	Expendable tail tank	5.9	13	~4285	168.7
10	$M_{\text{Tail2}}$	Non-expendable tail tank	8.9	19.6	~4510	177.6

**Table 6.3-1**
**NOTE:**

The moment arm of the main water ballast tanks is a conservative approximation - the moment arm changes from 200 mm to 247 mm as the main tanks are filled.

To determine if a selected loading falls within the CG envelope, as illustrated in Figure 6.3-2, the following procedure can be used:

1. List all the loads in table format as illustrated in Table 6.3-1
2. , (Include the mass and CG arm of the empty aircraft as obtained in the mass and balance report.)
3. Calculate the moments for each load, using the formula:

$$\textbf{Moment} = \textbf{Mass} \times \textbf{Moment arm}$$

4. Add the mass of the applicable loads
5. Add the moments of the applicable loads
6. Plot the mass against the moment on the JS-MD 3 Envelope diagram (Figure 6.3-2).
7. The Flying CG can also be calculated using the formulate:

$$\textbf{Flying CG position} = (\textbf{Total of Moments}) / (\textbf{Total Mass})$$

**Example:**

Determine if the following loading falls within the allowable envelope:

- Empty aircraft: 280 kg, CG position 470 mm
- Pilot with parachute weighs 90 kg
- Both main tank and expendable tail tanks filled to capacity.
- The non-expendable tail tank filled with 8.9 litres of water
- An O<sub>2</sub> bottle of 2 kg fitted.

(This example is given in metric units only.)

#	Loading point	Mass kg	Arm mm	Moment (kg.m) Mass x Arm/1000
	Empty aircraft	280	470	131.6
1	Pilot and parachute	90	-645	-58.1
3	Water ballast - main	138	247	34.1
4	Expendable tail tank	5.8	4285	24.9
5	Non-expendable tail tank	8.9	4510	40.1
8	O <sub>2</sub> bottle AL248	2	0	0.0
<b>Totals:</b>		<b>524.7</b>		<b>172.6</b>

**Table 6.3-2**

The plotted cross on the diagram illustrated in Figure 6.3-2 demonstrates that the CG is slightly aft of the mid position and just below the maximum allowable weight.

The flying CG can be calculated as follows:

$$\text{Flying CG} = \frac{\text{Total of moments}}{\text{Total mass}} = \frac{172\,600}{524.7} = 328.9\text{mm}$$

**The flying CG must be within limits given in Section 2.6.**



Figure 6.3-2 illustrates the envelope for the 15 m configuration.




Figure 6.3-2

Figure 6.3-3 illustrates the envelope for the 18 m configuration.




Figure 6.3-3

## 6.4 Optimisation of centre of gravity

The centre of gravity may be shifted toward the aft 25 % of the CG to obtain optimum climb performance. The procedure to set up the CG optimally is as follows:

1. Set up the sailplane with pilot in the empty configuration on the desired CG position (aft limit). This can be achieved by:
  - Add/remove permanent ballast and performing the following:
    - Redo the mass and balance.
    - Recalculate the new minimum and maximum cockpit loads as explained in the JS-MD 3 Maintenance Manual.
    - Update the Cockpit loads placard (Figure 2.14-2).
    - Update the weight and balance record (Table 6.2-1)
  - Add/remove removable ballast to change the empty (no water ballast) centre of gravity. Removable ballast include:
    - Tail battery.
    - Water in the non-expendable tail tank (top fin tank).
    - Removable nose weights.
2. When loading the sailplanes with water ballast, the expendable tail tank is used to offset the forward centre of gravity change due to water in the main wing tanks. Calculate the water quantity required in the expendable tail tank, and load accordingly.

When using this procedure, dumping water ballast in flight has no effect on the CG position.

**NOTE:** The removable ballast is used to change the centre of gravity (without water ballast) without affecting the approved weight and balance record.

### 6.4.1 Expendable tail tank

This tank is used only to offset the centre of gravity change due to the water ballast in the main wing tanks.

	Loading point	Mass		Moment arm	
		kg	lbs	mm	inch
$M_{TAIL1}$	Expendable tail tank	5.9	13	4240	167

Table 6.4-1

To offset the forward centre of gravity change due to water in the main wing tanks, the expendable tail tank must be filled according to the Table 6.4-2 given below.

Water in main tanks		Required water in tail tank	
Litres	US gallons	litres	US gallons
0	0	0	0.0
20	5.3	0.8	0.2
40	10.6	1.4	0.4
60	15.9	2	0.5
80	21.1	2.7	0.7
100	26.4	3.6	1.0
120	31.7	4.5	1.2
140	37.0	5.3	1.4
158	42.3	5.8	1.5

Table 6.4-2

### 6.4.2 Fuselage tanks (optional)

Fuselage tanks may optionally be installed instead of the fuel tanks of the sustainer system. Filling the fuselage tanks moves the centre of gravity aft. The required minimum cockpit weight is higher when water is added to the fuselage tanks.

The table below indicates the maximum weight and moment arm of the fuselage tanks.

	Loading point	Mass		Moment arm	
		kg	lbs	mm	inch
$M_{FTTop}$	Fuselage tank (top)	6.8	15	500.4	19.7
$M_{FTBot}$	Fuselage tank (bottom)	15.4	34	852.5	33.6

**Table 6.4-3**

Refer to the minimum cockpit weights placard (LH side of cockpit) or Table 6.2-1 for the difference in minimum cockpit load if fuselage tanks are filled. Figure 2.14-2 indicates an example of this placard.

When the tail battery is installed, use the "Minimum (i)" value on the cockpit placard for the tables requiring minimum cockpit weight given in the rest of this section.

### 6.4.3 Fuel tanks

Fuselage tanks are installed as part of the Jet Sustainer system. Filling the fuselage tanks moves the centre of gravity aft. The required minimum cockpit weight is higher when fuel is added to the fuselage tanks.

The table below indicates the maximum weight and moment arm of the fuselage tanks.

	Loading point	Mass		Moment arm	
		kg	lbs	mm	inch
$M_{FTTop}$	Fuel tank (top)	5.5	12.1	500.4	19.7
$M_{FTBot}$	Fuel tank (bottom)	12.1	27.7	852.5	33.6

**Table 6.4-4**

Refer to the minimum cockpit weights placard (LH side of cockpit) or Table 6.2-1 for the difference in minimum cockpit load if fuselage tanks are filled. Figure 2.14-2 indicates an example of this placard.

**NOTE:** When filling up the fuselage tanks ensure that maximum mass of non-lifting parts is not exceeded.

#### 6.4.4 Non-expendable tail tank

Adding water to the non-expendable ballast tail tank moves the centre of gravity rearwards. The required minimum cockpit weight increases when water is added to the tail tank.

The Table below indicates the maximum weight and moment arm of the non-expendable ballast tank.

	Loading point	Mass		Moment arm	
		kg	lbs	mm	inch
<b>M<sub>Tail2</sub></b>	Non-expendable tail tank	8.9	19.6	~4478	176.3

**Table 6.4-5**

Table 6.4-6 indicates the required loading (litres of water) in the non-expendable ballast tail tank to achieve the optimum centre of gravity position.

Non expendable tail tank loading requirements to obtain optimum cg (kg) (Fuel tanks full)							
Pilot + Parachute	60	70	80	90	100	110	
Minimum cockpit weight on placard (kg)	55	1.3	3.8	6.3	8.9		
	57	0.8	3.3	5.8	8.3		
	59	0.2	2.8	5.3	7.8		
	61	0.2	2.3	4.8	7.3		
	63		1.8	4.3	6.8		
	65		1.3	3.8	6.3		8.9
	67		0.8	3.3	5.8		8.3
	69		0.2	2.8	5.3		7.8
	71		2.3	4.8	7.3		
	73		1.8	4.3	6.8		
	75		1.3	3.8	6.3		8.9
	77		0.8	3.3	5.8		8.3
	79		0.2	2.8	5.3		7.8

**Table 6.4-6**

## **7 System description**

### **7.1 Introduction**

Section 7 gives a description of the aircraft systems together with instruction on the use of it. A detailed technical description of the systems with drawings can be found in the MD01-AMM-00-001 JS-MD 3 Aircraft Maintenance Manual Section 2.

The main aim of this section is to describe the controls, their labels and layout in the aircraft.



## 7.2 Cockpit controls

### 7.2.1 Elevator and aileron

The elevator and aileron are controlled conventionally by the control stick. Forward-aft movement deflects the elevators while sideways movement deflects the flapersons in the desired direction.

Various stick grip options are available with integrated instrument control buttons or just the radio transmit button (press-to-talk).

A leather boot covers the bottom of the stick. This boot must always be in position to prevent foreign objects from entering the control circuit below the cockpit seat pan.

The wheel brake is activated by squeezing a trigger on the control stick illustrated in Figure 7.2-1.



Figure 7.2-1

## **7.2.2 Rudder**

The rudder is controlled by the rudder pedals in the front section of the fuselage. Pushing either pedal deflects the rudder in the desired direction.

The rudder pedals fore and aft position is adjustable to accommodate different size pilots. The ergonomic controller on the right hand side of the cockpit is used to make adjustment either on the ground or during flight.

### 7.2.3 Flap

The flap control (Figure 7.2-2) is via a black handle located on the left-hand side of the cockpit. The flap handle can be freed from its detent by rotating it slightly clockwise as seen from the rear.



**Flap  
Lever**

**Figure 7.2-2**

The flap setting is indicated on the flap indicator plate (Figure 7.2-3), positioned just above the flap handle. It has six graduations. Flap settings 1, 2, 3, 4, 5 and L. Setting 1 is the most negative setting and setting L is the most positive setting.



**Figure 7.2-3**

## 7.2.4 Release system

The nose and CG hooks are operated simultaneously when the release handle is pulled towards the pilot.

The release handle is a yellow handle positioned on the left-hand cockpit side in front of the flap handle (Figure 7.2-4).




Figure 7.2-4

## 7.2.5 Trim

The trim of the aircraft is adjusted with a green knob located on the left side of the cockpit below the airbrake lever. The trim can be adjusted when the trim knob is pressed downwards.

Moving the trim knob has the following effect on the elevator control:

Forward - nose down force

Backwards - nose up force

The trim locks in the set position when the downward pressure is released.





Figure 7.2-5

## 7.2.6 Ergonomic control

The Ergonomic control panel provides the controls for the following subsystems:


- Rudder Pedals adjustment
- Cockpit Ventilation
- Demisting Ventilation
- Seatback Upper Adjustment (optional)
- Seatback Lower Adjustment (optional)

The auxiliary electrical system controller panel is situated on the right side of the cockpit behind the eyeball air vent. The controller unit consists of a Selector knob and an Adjuster Switch, illustrated in Figure 7.2-6.



**Figure 7.2-6 system controller panel**

The Selector knob is a 6-way rotary switch at 30 degree intervals, used to select the appropriate system to be adjusted.



**Figure 7.2-7: Selector knob layout**

The adjuster switch is a Momentary ON-OFF-ON Toggle switch, used to adjust the selected sub-system.

### **7.2.6.1 Rudder pedal adjustment**

To adjust the pedals, rotate the selector switch to "Rudder pedal" position. Adjust the pedal position using the control switch as follows:

- Up (+) - moves the rudder pedals away from the pilot
- Down (-) - moves the rudder pedals closer to the pilot

Multiple safety features in the rudder pedal adjustment includes:

- Built-in limit switches at both ends of travel
- Overload shutoff switch; this prevents pedal adjustment if pressure applied to the pedals

When the overload shutoff switch has been triggered the pedals can be adjusted without delay in the opposite direction. A two second delay prevents immediate movement in the original direction.



### 7.2.6.2 Seatback Adjustment (Electrical option)


The seatback can be adjusted in two ways:

- Seat Upper Adjustment
- Seat Lower Adjustment

To adjust the seat, rotate the selector switch to select either the upper or lower adjustment. Adjust the seat position using the control switch as follows:

- Up (+) - moves the seat rearwards
- Down (-) - moves the seat forwards

The seatback can be removed by lifting both spring loaded lock latches on the bottom of the seatback as shown in Figure 7.2-8.




**Figure 7.2-8**

**CAUTION:** To increase the service life of the gear motors, reduce pressure on the seatback while adjustment is in progress.

**WARNING:** Do not adjust the seatback during any acceleration conditions. This could result in damaging the gear motors.

### 7.2.6.3 Seatback Adjustment (Manual Option)


The bottom of the seatback can be moved forwards and rearwards by removing two thumb screw knobs on the seatback pivot point and setting the seatback to the desired position. (Figure 7.2-9)



Seatback  
lower  
adjustment

**Figure 7.2-9: Seatback lower adjustment**

The top of the seatback can be adjusted between an upright or reclined position by moving the seatback adjuster located behind the seatback. The seatback adjuster is unlocked by lifting both lock pins up and let it rest in the slot. (Figure 7.2-10)



**Figure 7.2-10: Seatback upper adjustment**

**WARNING:** Ensure that both thumbscrews and the adjuster locking pins are engaged before flying to prevent the pilot from shifting backwards. This could result in loss of aircraft control.

#### 7.2.6.4 Ventilation Control


The Cabin and Demisting Ventilation System is electrically adjustable via the ergonomic control panel.

To adjust the ventilation, rotate the selector switch to select either the eye ball vent or demisting function. Adjust the ventilation using the control switch as follows:

- Up (+) - increases airflow
- Down (-) - decreases airflow

Demisting air allows airflow to the area above the instrument combing.

The eye ball vent, positioned on the right hand cockpit sidewall is used to direct the airflow as desired. See illustration in Figure 7.2-11



**Figure 7.2-11: Cockpit Ventilation**

**NOTE:** Both the Cabin and Demisting Ventilation System open and closes reasonably fast, and only short clicks on the control switch is needed when neither fully opened or fully closed is required.

#### **7.2.6.5 Heated boots**

Heated boots can be plugged into an optional USB port located on the bottom of the instrument console. Switching power to this port is facilitated from the ergonomic control panel, as illustrated in Figure 7.2-6.


This can also be used to supply power to any 12V 2A device.

#### **7.2.7 Instrument panel**

The instrument panel is integral with the canopy and lifts to facilitate entering and exiting from the aircraft. The canopy can be removed from the instrument console by supporting the canopy and pulling back on both red jettison levers on the sides of the canopy frame.

The instrument layout is designed according to the owner's requirements, and approved by the manufacturer. There are various options that the customer can choose from.

Identification of instruments, switches and circuitbreakers installed on a custom designed instrument panel is illustrated in Figure 7.2-12. See Section 2.11 for instruments required as part of the minimum equipment list.




**Figure 7.2-12: Custom Instrument Panel Layout**

### 7.3 Landing gear system

The landing gear handle is located on the right-hand side of the cockpit and labelled as illustrated in Figure 7.3-1. Pulling the handle backwards retracts the landing gear and pushing it forward extends the landing gear. The handle is rotated firmly towards the cockpit side to lock in the extended and retracted position.

If a retractable tail wheel is fitted, the retractable tail wheel is extended mechanically with the main gear. When the main wheel is retracted, a spring retracts the tail wheel.



**Figure 7.3-1**

## 7.4 Seats and safety harness

The safety harness is a four-point system. The lower straps pass through the seat pan and are anchored to the fuselage skin. The shoulder straps pass through the seatback and are attached to the structure behind the pilot's shoulders.

**CAUTION:** Shorter pilots should add firm cushions (preferably energy absorbing cushions) on the seat pan to raise the body position in the cockpit. The cushion height should be sufficient to ensure the shoulder straps pull the pilot down positively.

**WARNING** No compressible cushions behind the pilot's back are allowed. A forward acceleration (e.g. a winch launch) may prevent the pilot reaching the controls safely if the cushions are of a compressible type.

The seat upper and lower seat back can be adjusted either mechanically or electrically. See Section 7.2.6 for more details.

## 7.5 Pitot and static system

The aircraft pneumatic system consists of:

- Static ( $P_{STAT}$ ) piping for ASI and Altimeter
- Dynamic ( $P_{TOT}$ ) piping for ASI
- Static piping for variometer from fin probe
- Total Energy (TE) piping from fin probe

The pneumatic piping is colour coded as follows:

- Static piping for ASI and Altimeter - Blue
- Dynamic piping for ASI - Green
- Static for electronic flight-  
Computer from multi-probe - Transparent/White
- Total Energy piping from fin probe - Red
- Mechanical variometer capacity - Yellow

Figure 7.5-1 gives a schematic of the instrument layout.

**NOTE:** The ASI must use the static sources located in the rear of the fuselage tube. The airspeed calibration values are based on these static port readings.

**NOTE:** Static ports located in the rear of the fuselage tube are marked with a red ring and must be kept unobstructed to ensure correct ASI readings.



Static  
ports on  
fuselage







Figure 7.5-1

## 7.6 Airbrake system


The airbrakes are actuated by the blue handle on the left-hand side of the cockpit (Figure 7.6-1).




**Figure 7.6-1**

The airbrakes are operated in the conventional manner:

- Pull the handle backwards to open the airbrakes. Figure 7.6-2 illustrates the cockpit label for the open airbrake position.
- Push the airbrake lever forward to close the airbrakes. Figure 7.6-3 illustrates the cockpit label for closed airbrake position.



**Figure 7.6-2**



**Figure 7.6-3**

Airbrakes can be locked in four different positions during flight. This is achieved by rotating the lever downwards into the detents.

The airbrakes are locked by moving the airbrake handle fully forward, over the over-centre lock. A force of approximately 15 to 20 kg is required to lock the airbrakes.

A damper restricts the rate of opening. This reduces high loads on the aircraft if brakes are opened at high speed.

## **7.7 Baggage compartment**

The maximum weight of items in the baggage compartment is 1 kg. This should only be used for soft items that will not injure the pilot in the event of a hard or crash landing. Ensure that the batteries that are carried in this area are secured with the battery straps and thumb screws. Ensure that the airflow holes in the rear are not obstructed as this might lead to a reduction in performance of the sailplane.

**BAGGAGE COMPARTMENT  
MAX LOAD: 1kg (2.2lbs)**

**Figure 7.7-1**

## 7.8 Water ballast system

### 7.8.1 General

The water ballast system allows the weight of the sailplane to be increased to a maximum of 525 kg (1157 lbs) in the 15 m configuration and to 600 kg (1323 lbs) in the 18 m configuration. The water tanks are integral type to the wings. Each inboard wing tank holds approximately 78 litres of water. Each 18 m wingtip holds approximately 16 litres of water.

There are two tail tanks to enable to pilot set the optimum CG position for a flight:

- The expendable ballast tail tank is positioned in the bottom area of the vertical fin with a capacity of approximately 5.8 litres
- The non-expendable ballast tail tank is positioned above the expendable tail tank in the vertical fin and has a capacity of approximately 8.9 litres. This tank is used to optimize the un-ballasted CG position.

The water in the non-expendable ballast tank can be drained after flight by removing the tape over the holes on the right-hand side of the fin.

A non-expendable ballast fuselage tank is accessible via the engine bay doors. This tank can be installed optionally if an engine is not installed.

The dump valve control is situated on the right-hand side of the cockpit. Pushing the lever forward opens both the wing tank valves and the expendable tail tank valve.



Figure 7.8-1

## **7.8.2 Main tanks**

The main tanks are integral in the main wings.

The dump valves are situated in the lower wing skin, approximately 400mm from the fuselage.

The filling holes are positioned on the top of the inboard wing section near the tip.

Filling is done through the top filling holes as described in Section 4.5.7.

The filling holes are closed by screwing the filler caps into position using the universal rigging tool.

The main tanks are vented through the vent holes in the filler caps. Optionally vent caps fitted with specially designed valves can be fitted. These valves will reduce water spillage through the filler caps when a wing is lowered.

## **7.8.3 18 m Tip tanks**

The tip tanks are integral in the 18 m tips only.

The dump valves are situated in the lower wing skin, approximately 100mm from the tip junction.

The filling is done via the dump valve as described in Section 4.5.7.

The tip tanks are vented through the vent holes positioned near the winglet.

Approximately 200 ml of water remains in the tank after dumping. This water must be drained by unscrewing the tip drain valve positioned aft of the tip dump valve.

## 7.9 Power plant

Refer to MD10-AFM-00-002 JS-MD 3 Jet Sustainer Manual.

## 7.10 Fuel system

Refer to MD10-AFM-00-002 JS-MD 3 Jet Sustainer Manual Section 7.

## 7.11 Electrical system

The electrical power of the aircraft is supplied by maintenance-free dry-gel type or LiFePO-4 12V batteries. Two main batteries are fitted in the luggage compartment and (as an optional addition) a backup battery can be installed behind the seat.

Overload protection is provided for each electrical system by circuit breakers. The rating for each system must comply with the specifications of the equipment manufacturer.

### 7.11.1 Electrical system description

A master switch arrangement enables the pilot to supply power to three independant systems:


- Avionic system
- Ergonomic system
- Jet system



**Figure 7.11-1**

Each sytem can individually be switched on or off.

Battery selection for the avionics and ergonomics systems are on a separate switch arrangement, allowing selection between the the Left, Right and Centre or auxiliary batterie (if installed).



**Figure 7.11-2**

The avionic system is divided into two busses, Bus 1 and Bus 2. This allows power supplied to the avionic system to be split in a primary and secondary system.

The following systems are installed as standard on the two busses:

**Avionic Bus 1:**

- VHF radio
- Primary flight computer
- Primary logger

**Avionic Bus 2:**

- Transponder (if fitted)
- Secondary flight computer
- Secondary logger

This arrangement allows the pilot to select power supplied to the primary and secondary system from separate batteries or from the same source.

### 7.11.2 Power plant Electrical System description

Power to the Jet System can be select from either the Left or Right battery. This is achieved by selecting the appropriate battery on the Jet Master switch arrangement.

Refer to JS-MD 3 Jet Sustainer Flight Manual Supplement Section 7.2 for more information on the electrical system.

### 7.11.3 Recommended battery types

The batteries used in the sailplane must be of the dry sealed type as no battery that vents any gas is allowed in the sailplane according the airworthiness requirements of CS-22.

Left Battery:            12 V 10 Ah LiFePO4 battery,  
                                  Dimensions: 151 mm x 65 mm x 93 mm  
                                  Fuse required for Avionics: 15 A  
                                  Fuse required for Jet: 25 A

Right Battery:            12 V 10 Ah LiFePO4 battery,  
                                  Dimensions: 151 mm x 65 mm x 93 mm  
                                  Fuse required for Avionics: 15 A  
                                  Fuse required for Jet: 25 A

Aux battery:              12 V 20 Ah LiFePO4 battery  
                                  Dimensions: 258 mm x 205 mm x 30 mm  
                                  Fuse required for Avionics: 15 A

**WARNING:**            Only use the batteries supplied with the aircraft or supplied by the JS representative. These batteries have circuit breakers at the terminals for overload protection, and protect the terminals from possible short circuits.

Refer to Figure 7.11-3 for the electrical schematic layout.






Figure 7.11-3

## 7.12 Miscellaneous equipment

### 7.12.1 Microphone and antenna

The plugs for microphone and antenna from the canopy frame are behind the instrument panel.

**CAUTION:** The radio microphone is located on the canopy frame. Take care when removing the canopy from the instrument panel that the microphone plug is carefully unplugged to avoid damage to the cables.

### 7.12.2 Trim weights

Optional trim weights can be installed behind the seatback. This option is normally not required as the sailplane is designed

### 7.12.3 Oxygen


Provision is made for an oxygen bottle on the left-hand side of the cockpit behind the seatback. If an oxygen bottle is used, ensure that it is secured properly using the locking bracket above the cylinder.

### 7.12.4 Bug wiper system

The bugwiper controls can be found on the left side of the cockpit in front of the trim lever.

If the bug wiper system is installed, perform the following checks before each flight:

- Check the operation of the bug wiper winding system. Ensure the wipers are set to wipe not closer than 500 mm from the winglet.
- Check that both wipers seat correctly in their garages when retrieved.
- Check the condition of the wiping cable and retrieve cable.
- Check that the stabilizing leg of the wiper opens between 70° and 90°.
- Check that the gaps between the fuselage and wings and between wing sections are correctly bridged. While wiping the wiper cleaning filaments may get caught in the gaps if not covered correctly. Figure 7.12-1 indicates how Piker-Storka suggests the covering of gaps between panels.



**Figure 7.12-1**

### 7.12.5 Strobe Light


An optional strobe light is recessed into the leading edge of the fin below the Pitot static and TE probes. The height of the strobe light is such that the sailplane fuselage does not obscure the light to other pilots, without blinding or distracting the sailplane's pilot.

The strobe light increases visibility especially in low visibility conditions or when approaching head on.

**NOTE:** The sailplane is not certified for night flying regardless if a strobe light is fitted

The strobe light is connected either directly to the battery or, if a LX Flarm ACL is installed, the Flarm anti-collision system.

The strobe light switch is located on the instrument panel. If connected to a Flarm ACL, the switch allows three modes of operation: ON, OFF and AUTO. AUTO lets the Flarm ACL activate the strobe light when in sufficiently close proximity to another sailplane.



**Figure 7.12-2**

If connected directly to the battery, the switch allows selection of either of the main batteries or OFF.



*Intentionally left blank*

## **8 Handling and maintenance**

Certain inspections and maintenance procedures to maintain the aircraft performance and reliability are included in this Section. It is advisable to follow a regular schedule of lubrication and preventive maintenance, consistent with the usage, climatic and flying conditions encountered.

For service and information not contained within this manual, it is recommended that the agent or manufacturer be contacted. All correspondence regarding the aircraft should carry its serial number.

The serial number can be found in the cockpit behind the back rest on the right-hand side of the fuselage.

## 8.1 Aircraft inspection periods

The aircraft shall be subjected to an annual airworthiness inspection. A more detailed inspection schedule can be found in the MD10-AMM-00-001 JS-MD 3 Aircraft Maintenance Manual.

- Airworthiness inspections must be performed in accordance with the relevant laws of the country in which the aircraft is registered.
- The manufacturer recommends performing a daily inspection, pre-flight check and cockpit checks as specified in Section 7.
- The manufacturer recommends performing additional inspections in certain circumstances (such as hard landings or ground loops) as explained in the MD10-AMM-00-001 JS-MD 3 Aircraft Maintenance Manual.
- Other inspections, maintenance or modifications to the aircraft, components or systems may be classified as "Mandatory" or "Recommended" according to issued Airworthiness Directives and Service Bulletins.

**NOTE:** The owner/operator is responsible to ensure compliance with all applicable Mandatory Airworthiness Directives.

- Personnel performing inspections and maintenance must be properly qualified in accordance with the relevant laws of the country in which the aircraft is registered.

## 8.2 Ground handling

### 8.2.1 Ground towing

Either use a rope or other non-metallic cable from the nose hook with someone walking with the wing tip, or

Use a tow bar connected to the tail dolly and a 'wing walker' with a sprung wheel (or someone walking with the wingtip).

**CAUTION:** Never tow the sailplane faster than walking pace.

**WARNING:** Do not push or pull on the wingtips.

### 8.2.2 Supporting area for road transport

- Fuselage:
  - Tail skid or tail wheel (with tail wheel fairing removed)
  - Main wheel
  - Shell in front of landing gear, minimum length of support 300 mm
- Wing:
  - Main spar at main pin hole closest to the root rib
  - Skin at root rib, minimum width of support 150 mm
  - Skin at 7.5 m, minimum width of support 250 mm
- Tailplane:
  - Anywhere on the skin, minimum width of support 80 mm



**WARNING:** The flaperon sandwich construction can be damaged if excessive force is used and should be handled with care.

**WARNING:** Removable tail wheel fairing can be damaged if not removed for road transport

### **8.2.3 Tie down**

The sailplane can be tied down using the holes in the wingtip skids. It is preferable to position wing stands under the wings inboard of the tip junction adjacent to the tie down ropes. A tie down rope across the rear fuselage boom in front of the fin should also be used to prevent the tail from lifting. It is advisable to restrain the rudder. Always tape the airbrake caps closed if there is a possibility of rain and remember to remove tape during the pre-flight inspection.

**NOTE:** It is recommended to use a brightly coloured tape to tape the airbrake caps.

## **8.3 Cleaning and care**

### **8.3.1 General**

The JS-MD 3 is manufactured from a composite of glass, carbon and aramid fibres in an epoxy matrix. The gel coat surface layer is finished with a polyurethane acrylic 2K paint topcoat.

There is no composite material available that is impervious to moisture absorption or to UV (ultra-violet) rays. UV rays will break down the epoxy matrix cross links and moisture absorption will damage the bond between the epoxy and the fibres, ultimately degrading the structural integrity of the aircraft. The utmost care must be taken to ensure that the structure of the sailplane is kept dry and not exposed to moist, hot or humid environments for protracted periods.

### 8.3.2 Paint and gel coat

The purpose of the outer surface finish is to present a good aerodynamic surface to the air when flying, but also to protect the structure from the environment. The main enemy for the structure is UV rays and moisture. UV rays will break down the epoxy cross links and will destroy the structural integrity of the aircraft. Gel coat protects the structure in a self-sacrificing fashion. The gel coat will degrade while protecting the structure. This will appear as cracks and yellowing. The gel coat can be protected by refinishing the aircraft with a Polyurethane Acrylic 2K paint system (factory finish process). Applying hard wax will not prevent UV damage to gel coat, but will slow down the surface deterioration.

Clean the outside of the aircraft with water and a mild detergent. Never use acetone or lacquer thinners to remove tape residue; rather use a silicon-free polish. Immediately after washing the sailplane dry it off with a soft chamois. Use special care not to allow water get into the hinge line and airbrakes.

**CAUTION:** Never use any of the following products on your aircraft:

- Trichloroethylene
- Carbon tetrachloride or similar hydrocarbon chlorides
- Any product containing silicon

### 8.3.3 Canopy

The canopy must be protected from scratches. Always wash off dust by using liberal amounts of water with a soft chamois, taking care not to allow dust get between the chamois and the canopy surface. Dry with a clean chamois. The canopy can be polished with a non-abrasive canopy polish with a rating of 5000 grid or higher.

Never clean the canopy with acetone or lacquer thinners as this will instantly create micro-cracks. Contact an M&D representative for recommended canopy polishes.

### 8.3.4 Cockpit interior

The inside of the cockpit can be cleaned with mild soap and water.

### 8.3.5 Water tanks

The sailplane should always be stored with the wing tanks open to ventilate. It is also a good idea to install a small electrical fan on top of the wing surface over the water filler hole to force ventilate the tank. This will allow the structure to dry completely and prevent any issues due to moisture absorption.

The O-rings on the water tank filler caps must be replaced if they start to age and crack. If the wing valves leak, the most probable cause is foreign matter below the valve seal and sealing ring. Wiping the area may solve the problem. The valve seal may also be cracked in which case a replacement can be obtained from an M&D representative. The seal can be replaced with some difficulty without removing the valve mechanism.

### 8.3.6 Pins, bushes and control systems

All bare metal surfaces that are not protected with paint must be protected with a thin film of grease.

### **8.3.7 Seat belt harness**

The seat belt harness must be checked regularly for frayed of edges, mildew and wear.

The Fittings and buckles must be checked regularly for corrosion and proper functioning. Also refer to seat belt harness manufacturers maintenance instructions.

### **8.3.8 Tow release**

Clean the nose and CG hooks regularly by means of pressured air and lubricate with spray oil. Also refer to the maintenance manual of the manufacturer.

### **8.3.9 Longitudinal push rod bearings**

Linear bearings are being used throughout the wing control system for the airbrakes and flaperon, and elevator control systems.

These bearings must never be greased or oiled. The oil and grease will pick up dust and foreign matter that will destroy the soft surface of the plastic balls.

## **8.4 Long-term storage**

### **Recommendations for storing the aircraft for long periods:**

1. Remove instruments and store separately
2. Close external pressure ports and inner tube end
3. Protect all metal parts using acid less spray oil or non-corrosive grease (Vaseline)
4. Close all orifices without preventing air circulation using wire cloth or similar means to prevent small animals from entering.
5. Drain all water tanks and force-ventilate water tanks until insides of the tanks are dry. Remove water filler caps and keep valves open during storage.
6. Leave the airbrakes unlocked on the ground (either rigged or de-rigged) to avoid loading the airbrake caps.
7. Store in an as-dry-as-possible environment

### **Return to service:**

Perform at least the same inspection as for the annual inspection. A typical inspection is included in the MD10-AMM-00-001 JS-MD 3 Aircraft Maintenance Manual.

Inspect wings and fuselage for small animals or nests and inspect the pneumatic system for blockage due to nests of insects.



*Intentionally left blank*

## 9 Supplements

### 9.1 Introduction

This section includes additional information on the safe operation of the aircraft if fitted with ancillary equipment not included as standard in the aircraft.

### 9.2 List of ancillary equipment

#### 9.2.1 Oxygen system

Provision is made for an oxygen bottle with a maximum diameter of 86 mm (3.4"). The oxygen bottle tube is installed through the bulkhead on the left hand side of the wheel box. The oxygen bottle must be correctly secured with the bracket provided.

Oxygen equipment installed:

- (a) Must be approved.
- (b) Must be free from hazards in itself, in its method of operation, and its effect upon other components.
- (c) Must have means to allow the pilot to readily determine, during the flight, the quantity of oxygen available
- (d) The pilot must be able to safely monitor and operate the system.





## JS-MD 3 Aircraft Flight Manual

MD10-AFM-00-001  
Issue: 00.21  
Date: 13.09.2017

*Intentionally left blank*

## 10 Service Bulletins

This section starts with an overview table of all optional SBs, in which the owner or operator should mark which SBs he voluntarily implemented and which not.

All implemented optional SBs have to be printed and added to this section by the owner or operator. Not implemented SBs do not need to be added to this section.

SB No.	Rev	Date	Description	SB implemented	
				Yes	No



*Intentionally left blank*

